



## HiCAD 2026 - What's new?

Version 2026

News Overview

Date of issue: 04/11/2025

[isdgroup.com](http://isdgroup.com)



THE WORLD OF CAD AND PDM SOLUTIONS



# TOC

<b>Discontinuations</b>	<b>9</b>
<b>Basics</b>	<b>11</b>
<b>Major Release</b>	<b>11</b>
New Ribbon	11
BOM-relevance of auxiliary and environment parts	11
Hide surfaces	12
Attribute Management	13
Automatic calculation and manual entry of attributes	13
Up-to-dateness of calculated attributes	14
Apply changes without restarting	15
Hiding internal HELiOS attributes	15
Drawing derivation	16
Annotation of sub-parts depending on part type	16
Dimensioning rule 57: Deleting duplicate dimensions	17
View orientation	18
Optimised closing of all drawings	19
Shaded with Hidden Line	19
Hide internal HELiOS attributes	19
Display the last drawings used in the Start Centre	20
Renewal of the Switch drawing window	21
Reset view rotation with ESC	21
<b>2-D</b>	<b>22</b>
<b>Major Release</b>	<b>22</b>
Sub-attributes in annotation tags	22
<b>3-D</b>	<b>23</b>
<b>Major Release</b>	<b>23</b>
Planning grid: Draw grid lines	23
Revision of the "Show/hide elements in view" dialogue	24
Standardisation of surface and plane selection	24
Shaded with Hidden Line	25
Standard processings	26
Creating user-defined forms	26
Bore depth and grid	27
Apply standard processings immediately	28
#43255Bore tables	28
Dimensioning symbols	29
Reference symbol as individual function	29
Automatic selection of arrowhead	29
Form and positional tolerance / Surface symbol / Reference symbol leader line	30
Form and positional tolerance - Combine identical features for adjacent rows	30
Universal delete function for dimensioning	31
Views	31
Update all views with a single button	31
Magnetic snap-in for view functions	32

Duplicating a drawing sheet .....	32
Save part list from view .....	34
Advanced catalogue search with multiple search terms .....	35
Cams .....	36
Cams: Filleting the corners of corner processings .....	36
Determine cam shape by sketch .....	37
Cam connection – multiple cam parts during processing .....	39
Special dimensions according to DIN EN ISO 129-1 .....	40
Improving the comprehensibility of Divide surface .....	41
<b>Point clouds .....</b>	<b>42</b>
<b>Major Release .....</b>	<b>42</b>
Reset clipping .....	42
Display of point clouds .....	43
Changed function names .....	44
<b>Feature Technology .....</b>	<b>45</b>
<b>Major Release .....</b>	<b>45</b>
Parameterisation of attributes without consideration of referencing settings .....	45
<b>Automation .....</b>	<b>46</b>
<b>Discontinuation .....</b>	<b>46</b>
<b>Major Release .....</b>	<b>46</b>
Favourites for dimension parameters .....	46
Create catalogue table from template .....	46
<b>Interfaces .....</b>	<b>47</b>
<b>Major Release .....</b>	<b>47</b>
Import as sub-part .....	47
IFC Import .....	48
Viewer .....	48
Move to HiCAD origin .....	48
Dots in attribute identifiers .....	49
Write IFC class to pipe parts during insertion .....	49
STEP Format .....	49
User-defined attributes .....	49
Performance .....	50
Part structure of the Navisworks export and other 3-D formats .....	51
<b>Sheet Metal .....</b>	<b>52</b>
<b>Major Release .....</b>	<b>52</b>
Panel - Make thermal break switchable .....	52
Punch and Bore pattern .....	53
Sheet along sketch .....	53
<b>Steel Engineering .....</b>	<b>54</b>
<b>Major Release .....</b>	<b>54</b>
Parameterisation of article number for Steel Engineering parts .....	54



Conical welded I-beams .....	54
New connection: Top plate .....	55
Insert new beam: Select processing plane .....	55
Bar list: Fixed-length beams and profiles with different cutting angles .....	55
<b>Metal Engineering .....</b>	<b>56</b>
<b>Major Release .....</b>	<b>56</b>
LogiKal interface - HiCAD information when updating processings .....	56
<b>Installation Planning .....</b>	<b>57</b>
<b>Major Release .....</b>	<b>57</b>
Direction of wall brackets .....	57
<b>Profile Installation .....</b>	<b>58</b>
<b>Major Release .....</b>	<b>58</b>
Exact representation for roof inclinations .....	58
<b>Plant Engineering .....</b>	<b>59</b>
<b>Major Release .....</b>	<b>59</b>
Step back in part insertion .....	59
Nominal diameter not written twice on guideline .....	59
Component connections .....	60
Minimum/maximum pressure .....	60
Connected parts for flange connection .....	61
Revision of nozzle insertion .....	62
Automatic placement of guidelines: Minimum angle for elbows .....	63
Write IFC class when installing pipe parts .....	63
Isometry and pipe spool drawing .....	64
Apply in the isometry update dialogue .....	64
Resolve 45° inclines in isometry .....	65
Pipe angle only for angles not equal to 90° .....	66
Link views generated in the pipe spool drawing .....	66
Symbol Editor: Structure database symbols according to classification .....	67
Isometry dialogue: Behaviour of options revised .....	68
HELIOS API .....	69
Document number via article master .....	69
<b>Catalogue Editor .....</b>	<b>70</b>
<b>Major Release .....</b>	<b>70</b>
Catalogue extension: Hollow profile DIN EN 10305-3 .....	70
Catalogue extension: Washers DIN 6319 C and DIN 6319 D .....	71
US Hollow Profiles AISC HSS RE (imperial) .....	72
Self-drilling screw JT3-FR-2H-4.8 .....	73
Alias name Flutz profiles renamed to Flutz aluminium profiles .....	74
Catalogue extension: EJOT self-drilling screws without sealing washers .....	75
Catalogue extension: Bore patterns and Punching tools .....	76
Implementation of Halfen HM Mounting rails and Halfen HS special bolts .....	77

<b>Bill of Materials / Report Manager</b>	<b>78</b>
<b>Major Release</b>	<b>78</b>
Search by alias name	78
Fixed length for Bar - Summary	78
BOM-relevance of auxiliary and environment parts	79
<b>Configuration Management</b>	<b>80</b>
<b>Major Release</b>	<b>80</b>
Apply attributes without restarting	80
Display of point clouds	80
Revised Show/hide elements in view dialogue	80
Switch drawing	80
Reference symbol	80
Annotation of countersunk holes	82
BOM-relevance of auxiliary and environment parts	82
View orientation during drawing derivation	82
Referenced parts with HELIOS article master	82
Automatic or manual calculation of attributes	83
Attributes for Steel Engineering	83
AutoPlace parts on guidelines: Minimum angle for elbows	83
PRODUKTEDITORKONFIG.DAT removed	83
<b>Notes on HELIOS Updates</b>	<b>85</b>
Notes on update installations	85
<b>HELIOS Desktop</b>	<b>86</b>
<b>Major Release</b>	<b>86</b>
Full-text search	86
Model structure and Document references	88
Document reference structure up-to-dateness	88
Checking outdated documents during printing, conversion and export, as well as when changing workflow status	91
Deleting referenced articles/documents in the model structure	93
Use in articles, Use in documents	94
Sorting the "Utilized items" result list	95
Convert: Further settings	96
Export dialogue: Progress bar with context determination	99
Job overview	99
HELIOS Options: Plugins	100
Update and save selected plugins	100
Plugin directory	101
Performance improvements for viewing	101
<b>HELIOS in HiCAD</b>	<b>102</b>
<b>Major Release</b>	<b>102</b>
Model structure	102
Document reference up-to-dateness, Document reference structure up-to-dateness	104
BOM-relevance of auxiliary and environment parts	105

Virtual attributes: Document number via linked article .....	105
Hiding internal HELiOS attributes .....	106
<b>HELiOS Spooler .....</b>	<b>107</b>
<b>Major Release .....</b>	<b>107</b>
HELiOS Spooler Admin Tool .....	107
Improvements to the priority processing of print and conversion jobs .....	108
<b>HELiOS MS Office Interface .....</b>	<b>109</b>
<b>Major Release .....</b>	<b>109</b>
Support of Office 2024 .....	109



# Discontinuations

## Discontinuation of Windows® 10

Microsoft® has discontinued support for the Windows® 10 operating system in October 2025. For compatibility reasons, HiCAD 2025 SP2 and HELiOS 2025 SP2 were the last versions of our CAD or PDM system to support Windows® 10. HiCAD 2026 and HELiOS 2026 no longer run under Windows® 10.

## Discontinuation of various HiCAD modules

Starting with HiCAD 2026 (Version 31.0), the following HiCAD modules will no longer be supported:

- **HiCAD classic and HiCAD creator**

The extension modules that previously required HiCAD classic or HiCAD creator now require HiCAD solution. Customers with a maintenance contract for one of the two modules will automatically receive HiCAD solution when they update.

- **HiCAD Sheet Metal suite**

Customers with a maintenance contract for HiCAD Sheet Metal suite will automatically receive Sheet Metal suite premium when they update.

- **Metal Engineering suite classic**

Customers with a maintenance contract for HiCAD Metal Engineering suite classic will automatically receive HiCAD solution when they update.

- **Report Manager professional**

The additional functionality of the Report Manager professional has been integrated into the Report Manager.

From HiCAD 2026 onwards, the following change to the module structure applies:

- **Steel Engineering suite premium**

The extension module Sheet Metal professional has been integrated into the Steel Engineering suite premium.

## Discontinuation of "old" OpenGL versions

From HiCAD 2021 on, only OpenGL version 4.3 is used in all HiCAD modules. Until now this was only the case with the module **HiCAD Point Cloud**. This means that HiCAD 2022 can no longer be run on computers without a separate graphics card. To avoid possible problems with onboard graphics cards, we recommend using a stand-alone graphics card.

## Discontinuation of the "old" Create detail drawing function

With the release of HiCAD 2012, the previously valid workshop drawing functionality in Steel Engineering had been extended to a function for general drawing derivation. The previous functions for [detail drawings](#) in Steel Engineering were still available in the [Detail drawing](#) section of the Drawing menu. As of HiCAD 2022 (Version 2700.0) these functions are no longer supported.

**Discontinuation of HELiOS 32 Bit, HiCAD Viewer 32 Bit and Office Interface 32 Bit**

Since HELiOS 2022 (Version 2700.0) there is no 32 Bit version available for HELiOS and the HiCAD Viewer. Since Microsoft has also offered a 64 Bit installation of Office since Office 2010 and many add-ins for Office are now also available as 64 Bit versions, with HELiOS 2024 we will support an Office interface only for a 64 Bit Office. If you are still using the Office interface in conjunction with a 32 Bit Office, you must uninstall your Office version and reinstall it as a 64 Bit version as soon as you update to HELiOS 2024.

**Discontinuation of CADENAS PARTdataManager**

As of HiCAD 2022 SP2, the CADENAS **PARTdataManager** will no longer be supported. Thus, the functions **Insert main part**, **PARTsolutions (CADENAS program)** and **Import PARTsolutions part** will no longer be available from SP2 onwards.

**Discontinuation of 3-D projection grid**

As of HiCAD 2023, the **3-D projection grid function** is no longer available.

**Discontinuation of Microsoft SQL Server 2012 and 2014**

Microsoft® discontinued support for **SQL Server 2012** in July 2022 and no longer provides security updates. As a result, **SQL Server 2012** will no longer be supported from **HELiOS 2025** onwards.

Also, Microsoft® discontinued support for SQL Server 2014 in July 2024. Therefore, SQL Server 2014 will no longer be supported from HELiOS 2026 onwards.

**Discontinuation of the "old" Report Manager**

From HELiOS 2024 onwards, the "old" Report Manager, i.e. the Report Manager up to 2022, will no longer be delivered with a standalone installation of the HELiOS Desktop. In a HiCAD/HELiOS installation or a HELiOS update of HiCAD, however, the "old" Report Manager is still included. From HiCAD 2025 onwards, only the "new" Report Manager as of 2023 will be supported.


**Discontinuation of Part insertion v26 (PE)**

The old **Part insertion** function in Plant Engineering has now been completely replaced by the new **Part insertion** function. Therefore, the function **Part insertion v26** in Plant Engineering is no longer available as of HiCAD 2024 SP1.

# Basics

## Major Release


### New Ribbon



The Ribbon has been modernised. In addition to a new design, the new Ribbon supports the use of 4K screens. This prevents scaling effects that could previously occur on icons when using high-resolution screens.

The QuickAccess toolbar is now located below the ribbon by default. The pull-down menu of the QuickAccess toolbar with configuration options has been replaced by a context menu that you can access by right-clicking on an empty space on the ribbon.



To start the **UserInterfaceEditor.exe** tool, which you can use to configure the QuickAccess toolbar and create your own ribbons, click on the  icon in the upper right corner of the ribbon and activate the Customize UI function.

## BOM-relevance of auxiliary and environment parts


Auxiliary and surrounding parts are often included in the drawing, but should not normally appear in BOMs.

If the BOM-relevance of already itemised parts is changed subsequently, this can lead to inconsistencies in the item numbers and texts, as described in the example **Itemisation - BOM-relevance of itemised parts under Further notes**.

For this reason, from HiCAD 2026 onwards, the procedure of creating auxiliary and surrounding parts outside the main assembly is supported. The following changes have been made for this purpose:



In the **Itemisation with options 1... n** dialog window, the **Only within the main assembly** option has been added to the **Numbering** section of the **General** tab.


The **Only consider parts within the main assembly** checkbox has been added to the **General** section of the **Bill of materials**  dialog window.

Two default settings have been adjusted in the Configuration Editor:

- The referencing setting for the **BOM-relevant** attribute at **System settings > Attribute management > Attributes** has been changed from "Do not transfer" to **Standard behaviour**.
- At **Modelling > Change part structure**, the **Move parts out of main assembly** checkbox is now enabled by default for all industries. Previously, this was only the case for Steel Engineering.

## Hide surfaces

The ALT key has been assigned the function of hiding surfaces of 3-D parts to make the facets underneath visible. To do this, move the cursor over the desired surface and press the ALT key. This works in every mode and during every function, even if the function does not require surface selection. The CTRL + ALT key combination shows the last hidden surface again. After exiting the respective mode in which the surfaces were hidden, all surfaces are automatically shown again.





An overview of the keyboard layout in HiCAD can be found [here](#).



## Attribute Management

### Automatic calculation and manual entry of attributes

Certain attributes in HiCAD, such as weight, surface area, volume, length and width, can be calculated automatically. Until now, automatic calculation of attributes could be disabled by activating the **%WFIX** attribute via the **Weight fixed** checkbox in the attribute mask. The **%WFIX** attribute and the checkbox have been removed. Instead, you can now individually set for each part and each attribute whether it should be calculated automatically or entered manually. To do this, right-click on the field behind the corresponding attribute in the attribute mask or in the ICN properties window. In the context menu that appears, select the option **Set attribute manually** or **Set attribute automatically**. Manually changed attributes will then be indicated with this symbol .








When loading old drawings in HiCAD 2026, the attribute **%WFIX** continues to be evaluated and affected sub-attributes are set to **Set attribute manually**. In the Configuration Editor, the attribute **%WFIX** then becomes an internal system attribute.


Further settings for attribute calculation can be found in the Configuration Editor at **System settings > Attribute management > Attribute calculation**.


## Up-to-dateness of calculated attributes

In the Attributes mask and in the Properties window of parts, icons in the fields of calculated attributes indicate the up-to-dateness of the calculation. The following statuses are distinguished:

-  Automatically calculated, Current
-  Automatically calculated, Outdated
-  Automatic calculation is locked
-  Manual entry
-  Different statuses (occurs when several different parts are selected in the properties window)

A description of the status is displayed as a tooltip when you move the cursor over the respective icon.



In order to identify parts with invalid attributes, the **Design Checker**  in the **General** category has been expanded to include two tests: **Parts with manually overwritten attributes** and **Parts with outdated attributes**.

### Apply changes without restarting

Changes to the attribute management in the Configuration Editor under **System settings > Attribute management > Attributes** will be applied immediately in HiCAD 2026 and later, without having to restart HiCAD. Previously, the attributes were read from the Configuration Editor once when HiCAD was started. With the new version, the attribute list is checked for updates when each function that offers attribute selection is started and reloaded if necessary. This affects:

- the **Text Editor**
- the **Attribute mask**
- the **P+ID attribute assignment**.

The **ICN properties window** is updated when the part is changed.


### Hiding internal HELiOS attributes

In attribute selection masks such as the **Annotation Editor**, internal HELiOS attributes are now hidden in addition to internal HiCAD attributes.


So-called internal attributes are HELiOS system attributes that are generally not relevant for end users when sorting result lists. They are therefore subtracted from the display in the attribute configuration by default, but can be included by deactivating the checkbox.

## Drawing derivation

### Annotation of sub-parts depending on part type

The **Drawing > Itemisation/Detailing > Derive... > Templates > Edit part annotation templates**  function allows you to edit the annotation templates for individual parts and assemblies that are used for part annotation in workshop drawings. When selecting a **Usage-dependent configuration** other than the **Default settings**, only three different flag types were previously available: for individual parts, assemblies/main parts and sub-parts. The selection of flag types for sub-parts has been expanded. Starting with HiCAD 2026, you can specify different annotation settings for the following sub-parts:

- Sub-parts, General
- Sub-parts, Profile
- Sub-parts, Plate
- Sub-parts, Sheet.




The settings are saved in an FTD file.

If an FTD file for sub-parts was changed before HiCAD 2026, the changes will be overwritten in the FTD file for general sub-parts when updating to the new version and will no longer apply to sub-parts of the type Profile, Plate or Sheet. In workshop drawings created before HiCAD 2026 and subsequently edited, the part annotation may change in such a case.

### Dimensioning rule 57: Deleting duplicate dimensions

When dimensioning overlapping sub-parts and standard processings perpendicular to the screen plane by means of Dimensioning rule 57, double chain dimensions may occur in workshop drawings. To change this behaviour, the parameter DELIDENTICSUBPARTCHAINS has been added to the STW\_DIMSETTINGS.XML file in the HiCAD SYS directory. If the value is set to 1, double dimensions are checked when workshop drawings are created using dimensioning rule 57 and deleted if found.



If the parameter DELIDENTICSUBPARTCHAINS does not yet exist in the STW\_DIMSETTINGS.XML file, it must be deleted manually once and HiCAD restarted.

Here you will find an overview of the dimensioning rules and information on the parameters of the STW\_DIMSETTINGS.XML file.



Please note that the new parameter only affects Dimensioning rule 57.

## View orientation


During drawing derivation of assemblies whose part orientation was not determined manually but via the part coordinate system of the main part, a deviation occurred when generating the front view. Compared to the front view determined by the part orientation, it was rotated by 90 degrees.

This behaviour has been changed, so that the front view created matches the front view of the part orientation. Drawings created before HiCAD 2026 that contain the described deviation will not be corrected during further processing, irrespective of the presetting.

In the Configuration Editor, under **Compatibility > Automatic drawing derivation**, the **View orientation of general parts and assemblies** list box has been added to maintain the old behaviour for new drawings.


The following options are available:


- **Front view = -Y** (new behaviour, default setting)
- **Front view = +Z** (old behaviour)





New and old behaviour when deriving the front view of the assembly HEA 200


## Optimised closing of all drawings

The query dialogue that appears when you call the **Close all drawings**  has been extended to include the **Apply to all drawings** checkbox. If this checkbox is selected, you will not be asked whether you want to save changes for each drawing individually.



## Shaded with Hidden Line

The icon has been changed so that the **Shaded with Hidden Line**  view mode in the QuickAccess Toolbar is more clearly distinguishable from the **Shaded with edges (3-D)**  quick view mode. In addition, when the **Shaded with Hidden Line** is activated, a message now appears informing you of possible longer waiting times that may result from hidden line calculations.



## Hide internal HELiOS attributes


In attribute selection masks such as the **Annotation Editor**, the internal HELiOS attributes are now hidden alongside the internal HiCAD attributes.

So-called internal attributes are system attributes of HELiOS that are generally not relevant for the end user when sorting result lists. They are therefore subtracted from the display in the attribute configuration by default, but can be included by deactivating the checkbox.

## Display the last drawings used in the Start Centre




The **Last used drawings** area in the **Start Centre** dialogue has been divided into the **History** and **Favourites** tabs. The star icon in the upper left corner of the preview image can be used to save or remove recently used documents from the **History** as favourites. This allows you to always access specific documents immediately, regardless of when they were last opened. Only a maximum of 16 documents are displayed in the **History**.





## Renewal of the Switch drawing window

The **Switch drawing** has been redesigned. It is now possible to open 96 drawings simultaneously. In addition, you can close a drawing by clicking the X in the upper right corner of the thumbnail. A HiCAD or HELiOS icon is displayed in the upper left corner of the thumbnail. This icon makes it easier to assign drawings. When you point the cursor at a thumbnail, a preview of the corresponding drawing is displayed.



## Reset view rotation with ESC

- If you dynamically rotate views using the middle mouse button (2-button mouse: both buttons) of the standard mouse, you can reset the view using the ESC key. To do this, you must hold down the mouse button.
- When you rotate a view using the SpaceMouse®, you can reset the view to its original position using the ESC key as long as you do not move the standard mouse. This requires that:
  - **Auto mode** is disabled (SpaceMouse® button: **Menu > Advanced Settings > Tab: Rotation Center**), and
  - in the HiCAD Configuration Editor under **System settings > Miscellaneous**, the option **End SpaceMouse mode by moving the mouse** has been activated.

## 2-D

### Major Release

#### Sub-attributes in annotation tags

Since **HELIOS** contains nested **Attributes**, i.e. attributes that contain further data, these sub-attributes can now be selected in the function **2-D Dimensioning + Text > Text > New** > **New text block**.

Examples of such attributes are customer and material.


Customer

- Name
- Customer number
- Phone number

Material

- Designation
- Density


These can be found in the **2-D text block** dialogue window under **Attribute...**:




## 3-D

### Major Release

#### Planning grid: Draw grid lines

The **Planning grid**  has been extended to include the option of drawing grid lines over a sketch.

The  button in the newly added **Additional drawn axes** area temporarily closes the **Planning grid** dialogue window and displays the **Process sketch** menu. You can then insert your own lines using the functions in the **Sketch > Draw** area and assign them a direction (X or Y) using the **Process sketch** menu. The following applies to the grid lines drawn:

- Individual straight lines, arcs and arc segments are permitted.
- The sketches can be edited with the Sketch HCM.

The lines are automatically sorted into the respective axis table and marked with the comment **Drawn**. This can be corrected afterwards using the arrow keys.

The projections set for the generated grid lines are not applied to the drawn lines.

The number of axes in the X and Y directions is displayed in the **Additional drawn axes** area. If no direction has been assigned to a drawn line, an error message appears there.

**- X-direction**

Number: 3

Mode: Different individual distances

	Intermediate distance	Designation	Levels
1	0	A	All
2		A'	All
3	1000	B	All
4	1000	C	All

Angle: 0 Projection: 100

**- Y-direction**

Number: 3

Mode: Different individual distances


	Intermediate distance	Designation	Levels
1	0	1	All
2		1'	All
3	1000	2	All
4	1000	3	All

Angle: 0 Projection: 100


**- Levels**

**- Additional drawn axes**




Drawn axes X: 1; Y: 1



## Revision of the "Show/hide elements in view" dialogue

To improve the clarity of the **Show/hide elements in view**  , several changes have been made:

The meaning of the icons has been changed. The following options are now available for the visibility of elements:


-  Display normally and hide in Hidden Line mode,
-  Hide,
-  Display and do not hide in Hidden Line mode.

When you start the dialogue for the first time after updating to the new version, a message will be displayed informing you of the change.

In the Configuration Editor, under **Drawing > Views**, the **Hiding and overlapping of edges** area has been renamed to **Show and hide elements**. Here you will find the default settings of the dialogue window. The names in this area have been largely aligned with the names in the dialogue. This also applies to the names under **System settings > Visualisation > Views > Insertion view**.


## Standardisation of surface and plane selection

Surface selection has been standardised for all functions in the **3-D Standard** and **3-D FFS** areas. With the new surface selection, surfaces are completely highlighted with their edges as soon as you move the cursor over them and can be selected using the LMB.



You can use the ALT key to hide the surface under the cursor. This allows you to select hidden surfaces without having to rotate the drawing or change the view. The key combination CTRL + ALT shows the last hidden surface again.

It is still possible to select a surface across two edges, as was previously the case with some functions. To do this, move the cursor over a single edge and wait until only the single edge is highlighted before selecting it. You will then be prompted to specify a second edge to completely define the surface.




It is still possible to select a surface across two edges, as was previously the case with some functions. To do this, move the cursor over a single edge and wait until only the single edge is highlighted before selecting it. You will then be prompted to specify a second edge to completely define the surface.

The selection has also been standardised for all functions that require a plane to be selected. This is now done in the same way as when creating a processing plane.

## Shaded with Hidden Line



To make the **Shaded with Hidden Line** view mode in the Quick Access Toolbar more distinct from the

**Shaded with edges (3-D)**  quick view mode, the icon has been changed. In addition, when the **Shaded with Hidden Line** mode is activated, a message now appears informing you of possible longer waiting times that may result from hidden line calculations.

## Standard processings


The dialogue window **Bores, Countersinks, Threads**



function for creating standard processing operations

has been expanded:

### Creating user-defined forms



The **User-defined form** has been added. The new Form provides access to sample tables from the **Bore patterns** and **Punching tools** catalogues, where you can save your user-defined bores as sketches.

In order to use your sketch as a bore pattern, it must be parameterised with the Sketch HCM and then saved in KRA format. It is also possible to create the bore as a 2-D part and save it in DCF format. However, we recommend using the sketch variant, as it offers significantly higher quality advantages.

The new table **Rectangle (filleted)** has been added to the **Bore patterns** catalogue and the new table **Keyhole** has been added to the **Punching tools** catalogue. These each contain an ISD-side example.




The **User-defined form** replaces the old functions **Bore pattern** and **Punching tools**. The old functions can currently still be found under **3-D Standard > Standard Processings > Bore/Thr. > Up to HiCAD 2025** or under **Sheet Metal > Further tools > Moulding tools > Up to HiCAD 2025**.

## Bore depth and grid

### Bore depth

The option **To point** is now available as an additional mode for specifying the **Bore depth**. By selecting a point, the new option allows you to determine the end of the hole. In addition, you can specify a distance from the end of the bore tip to the point.



When specifying the **Bore depth** above a certain value using the **With drilling depth** mode, an arrow pointing in the direction of the bore is displayed in the preview, starting from the tip of the bore. By dragging the tip of the arrow with the cursor, the **Bore depth** can be changed manually afterwards. To distinguish this arrow from the arrows that mark grid positions where the part is not hit, the colour of those arrows has been changed.

Furthermore, the settings made for the **Bore depth** remain unchanged when changing the **Form**, as far as this is reasonably possible.

The **Perpendicular for laser cutting** option is now also available when the bore depth is set to **Through**. Previously, this option was only available in **Next exit surface** mode.


### Grid

If **Radial** mode is selected in the **Grid** configuration window while the current processing plane is tangential to a cylinder surface, the cylinder surface is now automatically marked as the new processing plane. The same applies if a plane tangential to a cylinder surface is already selected and then switched to **Radial** grid mode.

### Apply standard processings immediately



In the **Bores, Countersinks, Threads** function dialogue, the **Apply immediately** checkbox has been added to the lower area. If this checkbox is activated, the settings made are inserted immediately as soon as they are complete. The dialogue window remains open after the settings have been applied.



### #43255 Bore tables


Standard processing created using the **Bores, Countersinks, Threads** function will also be taken into account in the bore tables from HiCAD 2026 onwards.



## Dimensioning symbols

### Reference symbol as individual function

Since the **Reference symbol** is used as a reference point for both the **Form and positional tolerance** and the **Surface symbol**, a separate function has been created in the ribbon. This means that it is no longer necessary to create a **Reference symbol** in the **Form and positional tolerance** function.



### Automatic selection of arrowhead

The reference line end for **Form and positional tolerances**, **Surface symbols** and **Reference symbols** can now be generated automatically. The function can be activated in the **Configuration Editor** under **Drawing > Annotations > Form/Positional tolerance** and the corresponding setting **Select end of reference line automatically**.



#### Please note:

- Note that the automatic selection does not take overlaps into account. For this reason, it is recommended to make the change either before or after creation.
- For cylinder surfaces, an arrow is always generated, which can be processed afterwards.

### Form and positional tolerance / Surface symbol / Reference symbol leader line

The **Surface symbol** function dialogue window offers three options that determine how the surface symbol is displayed. The first option is to create the surface symbol without a leader line. The second option is to create the surface symbol without a leader line by default. This means that when you click on a surface, a leader line is created. However, if you click on an edge, the surface symbol can be placed there directly. The last option always creates the surface symbol with a leader line.



The **Form and positional tolerances** function dialogue window offers three options for specifying how the tolerance is displayed. The first option allows the tolerance to be placed freely, without a leader line or base point. The second option allows a tolerance to be created with a base point. Finally, the last option allows the tolerance to be created with a reference line and base point.




There are two options to choose from in the **Reference symbol** function dialogue window. These two options can be used to specify whether the reference symbol should be created with or without a leader line.




### Form and positional tolerance - Combine identical features for adjacent rows

If you have two overlapping tolerances with the same symbol in the **Form and positional tolerances** function, you can activate the **Combine identical features** checkbox. This will display only one symbol at the front that applies to the specified tolerances.



## Universal delete function for dimensioning




Several deletion functions from the **3-D Dimensioning+Text** area have been combined in the **Delete** function. The new function can be found under **3-D Dimensioning+Text > Delete**. The old deletion functions for dimensions and texts can be found under .

With the new function, you can delete the following objects:

- Dimensions of any kind
- Weld symbols
- Form and positional tolerances
- Surface symbols
- Edge state
- Annotations
- Item numbers
- Reference lines
- 3-D texts
- Grid annotations
- Tables

The selected object is deleted after selection and another selection can be made. Press the **ESC key** to exit the function. Use the **CTRL+LMB** key combination to draw a rectangle in which everything mentioned above will be deleted. You can also delete a structure using the **CTRL+LMB** key combination. Use the **RMB** to open the context menu.



There are three options available in the context menu. First, you can select **Rectangle**. This allows you to draw the same rectangle for deletion as with the key combination **CTRL+LMB**. Via **Active view**, all objects are deleted from the active view. The last selection is **Drawing**. With this option, all objects are deleted from the entire construction **across all sheets**.

## Views

### Update all views with a single button


Changes have been made to the **Update sectional views in active sheet/model** and **Update all sectional views** functions, as these functions now also update details, cut-outs and exploded views. The new names are as follows:



**Update views for changed parts (in active sheet/model)** and **Update views for changed parts (in all views)**



. The context menu **Update views** also contains the new category **Recalculate developments**. You can use the two functions **Active view** and **All views** to update developments. This applies to sheet and surface developments.



### Magnetic snap-in for view functions

The following viewing functions have been extended to include magnetic snap-in:


- Views > New > New view, horizontal/vertical
- Views > New > New view, In direction of (3-D)
- Views > New > Copy 3-D view
- Views > New > Sectional view (3-D)
- Views > New > Detail view Cuboid/Sphere

### Duplicating a drawing sheet

You can now create a copy of a sheet area in the ICN under **Views**. To do this, open the context menu and select the






**Duplicate** function. This can be used for both the active and inactive sheet areas. Multiple selection or selection of the model area is not possible with this function. This function duplicates everything from the selected sheet area.




## Save part list from view

Three new functions have been added to the context menu of the views under Hide/Show parts:


-  Set current part list of the view as required part list
-  Load required part list of the view
-  Delete required part list from view

With the **Set current part list of the view as required part list** function, you can create a required part list from the currently visible parts. If you have added parts to the view or hidden parts, you can use the **Load required part list of the view** function to call up the required part list you created. If the required part list is no longer needed, you can remove it using the **Delete required part list from view** function.



## Advanced catalogue search with multiple search terms

In the **Catalogue**, it is now possible to specify multiple search criteria as search terms simultaneously. The search results displayed always meet all search criteria. To include multiple search criteria in the search term, it is essential to separate the individual search criteria with a semicolon ;.






## Cams

### Cams: Filleting the corners of corner processings


The **Fillet radius** parameter has been added to the **Cams** function. This can be activated by a checkbox. Please note that the fillet radius only affects the corner processing of the cams.






## Determine cam shape by sketch


In the **Cams** function, the new **User-defined form** option is available under **Cam shape**. This option allows you to use your created sketches as cams. A sketch can be selected from the **Catalogue** in the **Parameters** under **Cam shape**.




The sketches you have created, parameterised with HCM and assigned variables, must be saved as **KRA files** in the HiCAD folder ...\\HiCAD\\Kataloge\\Werksnormen\\Nockenformen.



In the Catalogue Editor, under **Catalogues > Factory standards > Cam shapes**, create a new table using **New table with template** from the context menu.





The sketch must be stored in the new table, the parameter dimensions must be specified, and the table must be saved. The new table is now available in the catalogue of the **User-defined form** option.




### Cam connection – multiple cam parts during processing

A list box has been added under **Parts with cams** in **Cam processing**. First, select the part to be processed. In the next step, select all parts that collide with the selected part due to cams. The **Properties** and the **Corner processing** of the cut-outs can be customised for each part.




## Special dimensions according to DIN EN ISO 129-1

According to DIN ISO 120-1, special dimensions can be used to describe bore depth and countersinks. The corresponding standard for the annotation of countersunk and blind holes can be set in the **Configuration Editor**. To do this, go to **System settings > Annotations > Part annotation > Standard for annotating countersunk holes** and change the value from **Standard designation according to DIN ISO 15786** to **Special dimensions according to DIN ISO 129-1**.




You can also access the **Settings for annotations** function in the **Ribbon** under **3-D Dimensioning+Text > Text > Standard designation** using the arrow . There you can change the setting for the annotation of countersunk and blind holes from **According to DIN ISO 15786** to **According to DIN ISO 129-1**. After the change, all standard designations are updated so that the current standard is always used in the drawing. You can use the **Standard designation** function for countersunk and blind holes for which a special dimension is to be created.



## Improving the comprehensibility of Divide surface

To make the **Divide surface** function easier to understand, the names of the two modes have been changed. They are now called **Divide selected surfaces perpendicular to sketch** and **Divide with straight lines from points on edge of surface**. In addition, the icon for selecting the lines has been changed in the second mode. The text in the Info bar for selecting the graphic has been changed to **Select edge point of surface to be divided**.




## Point clouds

### Major Release

#### Reset clipping




The new **Reset clipping** function deletes all subtractions and resets the clipping to the original boundary. This makes the entire point cloud visible. You can access this function by selecting **Edit boundary** and then opening the context menu with a right-click.






## Display of point clouds

The settings for the graphical representation of the point cloud have been expanded. You now have the option to

make the following changes using the **Settings**  function:

- **Brightness:** Here you can dynamically change the brightness using the slider (in increments of 0.1). The default value is 1, which means that the point cloud becomes darker below 1 and brighter above 1.
- **Improved display:** This filter darkens small areas that are shaded by nearby objects. This gives the point cloud more depth and realism.
- **Emphasise edges:** This filter compares the depth of each pixel with that of its neighbouring pixels to emphasise the edges and contours of objects. This makes the shapes in the point cloud clearer. The filter is only active if you have also activated the **Improved display** option.
- **Blur:** This reduces the contrast of the point cloud, creating smoother transitions. The filter is only active if you have also activated the **Improved display** option.


The options set for the display of point clouds apply to all point clouds in the design and will be memorized when you save your drawing.



(1) Default setting, (2) Improved display, (3) Increased brightness, improved display and emphasized edges, (4) Improved display and Blur

The Colour mode can be selected in the **Properties** window (ICN) of the point cloud. In addition to the scanned colour, there are two additional options:

- **User-defined colour mixed:** With this option, the intrinsic colour of the point cloud and a highlight colour are mixed in equal proportions. You can select the highlight colour from the system colours or drawing colours.
- **User-defined colour:** With this option, only the highlight colour from the system colours or drawing colours is used.




(1) Colour mode: Custom colour, (2) Highlight colour: Green

## Changed function names

For the sake of more clarity, the following function names have been changed:

Clipping Box Manager > **Clipping Manager** 


Edit clipping box > **Edit boundary** 



# Feature Technology

## Major Release

### Parameterisation of attributes without consideration of referencing settings

For the **Parameterise part attributes**  function, the referencing settings from configuration editor under **System settings > Attribute management > Attributes** are no longer taken into account. Previously, attributes with the referencing setting **Do not transfer** were not displayed in the selection dialogue of the function.

From now on, all attributes are displayed in the selection dialogue, regardless of the settings in the Configuration Editor.

You can find the **Parameterise part attributes**  function at **3-D Standard > Tools > Attr.**  **> ....**

# Automation

## Discontinuation

### Discontinuation of the ISD.PDM.API

Before carrying out a HELiOS update for an older HiCAD version, please note that from HELiOS 2022 onwards, the previous ISD.PDM.API will be discontinued and replaced by the new API from Helios.Interface. If you use customisations that use functionalities from the previous ISD.PDM.API, you must update the customisations to the new API before carrying out the HELiOS update. If you use customisations that use functionalities from the HiCAD API, you should ensure that the HiCAD version used is at least version 2502.5 or 2601.1 or newer. If you are unsure whether you are using corresponding adaptations, please talk to your administrator or contact the ISD in case of doubt.

## Major Release

### Favourites for dimension parameters



You can save favourites in the **Dimension Parameters** dialogue window. To select these favourites when dimensioning, the HiCAD API provides the command

- `DimensionSettings.Load()`

### Create catalogue table from template

With the HiCAD API, you can now create empty catalogue tables from existing templates. Use the command

- `CreateTableFromTemplate()`


# Interfaces

## Major Release

### Import as sub-part

In earlier versions, parts in foreign formats could only be imported into an existing HiCAD drawing as main parts.

Starting with HiCAD 2026, it is also possible to insert them as sub-parts via interfaces, for example via the context menu of parts.




This applies to both import via **Insert > Sub-part > Interfaces > 3-D Import**, and via **3Dfindit**.

## IFC Import

### Viewer


When importing IFC files, the IFC import filter window also provides a viewer that you can use to mark individual or multiple parts as exceptions to the import.



### Move to HiCAD origin

In the past, when importing IFC files that did not contain a project coordinate system, geometries located far from the origin in the drawing could become unmanageable in HiCAD due to the resulting loss of accuracy.

HiCAD now asks whether such geometries are present during import and displays a query if necessary.



Confirm with **Yes** to move the IFC model to the HiCAD zero point.

If you click **No**, the IFC file is imported as is without being moved.

In this context, please also note that it is generally advisable to activate the import option **Transform IfcSite to origin**.

## Dots in attribute identifiers

With the update to HiCAD 2026, attribute identifiers can also contain points (example: "COBie.Component.TagNumber").

## Write IFC class to pipe parts during insertion

Starting with HiCAD 31.0, the HiCAD attribute **IfcType** is automatically assigned an IFC class when pipe parts are inserted. The assignment of part types to the corresponding IFC classes can be customized via the file **Install/PlantParts/IfcConfig/PartTypeIfcClassMapping.txt**.


In addition, it is possible to assign an IFC class directly to a VAA/PAA. To do this, the HELIOS attribute **IFC\_CLASS** is added to your HELIOS database when you execute the function **Update HELIOS for Plant Engineering** in the **DBPlantDataImport.exe** tool.


## STEP Format


### User-defined attributes

HiCAD supports the import and export of user-defined attributes of the STEP format.


Similar to the configuration of attributes for Navisworks export, these can be controlled via an XML file.

The imported attributes of a part or assembly can also be viewed via the interface marking of the 3-D part structure in the ICN (right-click  > **Import attributes**).





You can also view the attributes via the tooltip:



## Performance

A significant performance increase has been achieved for the STEP format, especially when exporting colours and layers on a larger scale..

## Part structure of the Navisworks export and other 3-D formats

To improve the collision check when exporting to the Navisworks format, threads and sub-parts of Sheet Metal parts are not exported as separate parts, but their geometry is included in the superordinate part or the Sheet Metal main part.

This change also affects exports to SketchUp, VRML and Gamma-Ray formats.


In addition, referenced parts that occur multiple times are only exported and referenced once in the Navisworks export, as is also the case with IFC exports.

# Sheet Metal

## Major Release

### Panel - Make thermal break switchable

During the insertion of flat panels (without offset), HiCAD 2026 or later allows you to insert either an insulation or a continuous thermal break. The thermal break at the edge is also optional for insulations.




- (1) If insulation is selected, the continuous thermal break is greyed out,
- (2) If a continuous thermal break is selected, the insulation is greyed out,
- (3) Insulation with thermal break at the edge



## Punch and Bore pattern

Since the Punch and Bore pattern functions have been integrated into the **Bores, Countersinks, Threads**




option **User-defined form**  dialogue window, you can find the corresponding old functions at::

- Menu bar: **Sheet Metal** > Function group: **Further Tools** > Pull-down menu: **Mould** > Up to HiCAD 2025 >


**Punch**



- Menu bar: **3-D Standard** > Function group: **Standard Processings** > Pull-down menu: **Bore/Thr.** > Up to HiCAD 2025 > **Bore pattern**  .

## Sheet along sketch

Previously, the **New sheet along sketch** function could only be used to create sheet metal parts from sketches with degrees and circles. This restriction has been removed, so that any lines can now be used. The resulting bend zones follow the course of the curves, meaning that they are not cylindrical. These bend zones are referred to as rolled bend zones and are not taken into account in the allowance method. In the development, rolled bend zones do not receive bend lines..




(1) Sheet along sketch dialogue window, (2) Feature log, (3) Automatically inserted bend zone, (4) Rolled bend zones


# Steel Engineering



## Major Release

### Parameterisation of article number for Steel Engineering parts

The manually selected article number for beams, profiles, sheets and plates can now also be edited using the **Parameterise part attributes**  function.


### Conical welded I-beams

The new function **Conical welded I-beam** has been added for insertion and configuration of conical I-beams. The beams are constructed in several parts and consist of plates that are welded together. The sheets used are selected from the catalogue. Different sheets can be selected for different components, including for the upper and lower flanges. In addition, stiffeners and top plates can be inserted at the start and end of the beam. All components of the beam are automatically combined in an assembly after insertion. Beam insertion is carried out in the same way as the **Insert new beam**  function.






## New connection: Top plate

The **Top plate** connection has been added to the Steel Engineering functions. This function can be used to connect a beam via a top plate to two other intersecting beams that are perpendicular to the first beam.



## Insert new beam: Select processing plane

The **Insert new beam**  function dialogue has been expanded to include the new **Select processing plane**  option. This allows you to change the plane at any time during beam insertion.



## Bar list: Fixed-length beams and profiles with different cutting angles



Previously, fixed-length beams and profiles with the same length were grouped together in a row when creating bar lists, even if they had different cutting angles. Starting with HiCAD 2026, beams and profiles with the same fixed length but different cutting angles are listed separately.

# Metal Engineering

## Major Release

### LogiKal interface - HiCAD information when updating processings

The **Log** dialogue window, which is opened by the **Transfer changes in HiCAD to LogiKal** function, displays the processings that have been made. A green tick indicates that the processing will be transferred to LogiKal. If a red X is displayed, transfer is not possible. In this case, the short description also indicates that the processing cannot be exported. Otherwise, it notes which processing is involved. If you click on an processing in the dialogue window, it will be highlighted in the Sheet.




# Installation Planning

## Major Release

### Direction of wall brackets

The **Wall brackets** dialogue window has been expanded to include the **Direction** option. You can now manually select the upward direction **Direction (Top)**. This option allows wall brackets to be installed when the substructure has not been installed vertically upwards, but horizontally under the ceiling, for example.




(1) Wall plane, (2) Direction of installation

## Profile Installation

### Major Release

#### Exact representation for roof inclinations

When installing trapezoidal sheet metal profiles with at least two roof surfaces (and at least one roof ridge), the profiles are now bent, provided that the installation angle allows this. The installation angle of the profile must be selected so that the length of the profile runs parallel to the roof ridge. Only profiles made of one component are bent, not profiles with insulation. The profiles are bent at the lower edge of the material. This means that a trapezoidal profile can be bent in the upper flange, in the lower flange or even in between, but not in the neutral axis. If the bending point causes conflicts in a representation, a straight profile is inserted for this representation.



(1) Bent trapezoidal sheet, (2) Bending point at lower edge of material




# Plant Engineering

## Major Release


### Step back in part insertion

When inserting on a guideline part insertion, it was previously not possible to select a guideline other than the one previously selected as the insertion target. To do this, you first had to switch to the part search and then back to part insertion. For this reason, the **Step back** option has been added to the context menu.



### Nominal diameter not written twice on guideline

The nominal diameter of guidelines was previously found in the **Part attributes** mask under the dba attribute **Quantity 1**. In HiCAD 30.2, the nominal diameter was also listed under **Nominal diameter**, so that this value appeared twice. This duplication has been removed in HiCAD 31.0. A conversion routine was developed to ensure that old scenes could still be used despite the change. This involves moving the entries from **Quantity 1** to the **Nominal diameter** field.



(1) Value in two places in HiCAD 30.2, (2) From HiCAD 31.0 onwards, the value can only be found under **Nominal diameter**.

## Component connections

### Minimum/maximum pressure

The **Component connection dialogue** includes the option to specify the connection option. For the **Flanged** connection option, a function has now been added to specify a minimum and maximum pressure. Two new input fields, **Min. pressure** and **Max. pressure**, have been added for this purpose.

This pressure value is used when searching for a suitable flange if a flange is connected to the component connection.

**Add connection**

**Part to be processed**

EN 10216-2 {Rohr} {0}

Point

Name: ~CompJoint\_0005

**Connection**

Options: Flanged

Sealing surfaces: Form A/B - Form A/B

ID: 20000

☒ Direction

Thickness of flange plate: 0

Max. pressure: 42

Min. pressure: 8

**Dimensions**

Nominal diameter type: Nominal diameter (DN)

Nominal diameter: 100

Wall thickness: 0

Outer diameter: 0

☆ OK Cancel Apply



## Connected parts for flange connection

For **Component connections** with flange connections, the shape of the **Sealing surfaces** and the type of components to be connected can now be conveniently defined.

**Add connection**

**- Part to be processed -**

(BEH1) {Beispielbehälter 1} {0}

Point

Name: Flanschanschluss1

**- Connection -**

Options: Flanged

Sealing surfaces: Form A/B - Form A/B

ID: Direction

Thickness of flange plate:

Max. pressure:

Min. pressure:

**- Dimensions -**

Nominal diameter type: Nominal diameter (DN)

Nominal diameter: 100

Wall thickness: 0

Outer diameter: 0

**Form A/B - Form A/B**  
*With component connection form A/B, the side to be connected should always follow with form A/B.*

**Form A/B - flanged pipe + loose flange**  
*For component connection form A/B, the side to be connected should always follow with a flanged pipe + loose flange.*

**Form A/B - welding neck + loose flange**  
*For component connection form A/B, the side to be connected should always follow with a welding neck + loose flange.*

**Form A/B - pipe + plane flange**  
*For component connection form A/B, the side to be connected should always follow with pipe + plane flange.*


**Form C/E (tongue) - Form F/D (groove)**  
*With component connection form C/E (tongue), the side to be connected should always follow with form F/D (groove).*


**Form F/D (groove) - Form C/E (tongue)**  
*With component connection form F/D (groove), the side to be connected should always follow with form C/E (tongue).*

☆ OK Cancel Apply

In addition, the **AutoPlace** has been expanded. If the **Counter-flange** checkbox is activated in the corresponding dialogue window, the selected components are automatically inserted.

## Revision of nozzle insertion

The **Fit nozzle in vessel**  function has been fundamentally revised. Instead of several consecutive dialogues, there is now a single dialogue window in which all settings are clearly summarised. The basic range of functions remains the same, but operation has been simplified.




The new dialogue window contains the following options:

- **Type of insertion:** Various options are available for straight pipes (mounted, inserted projecting, inserted flush) and elbows (mounted).
- **Nozzle dimensions:** The lengths **Length, inner (LI)** and **Length, outer (LA)** are specified directly in the dialogue window. For elbows, the **Elbow angle** can also be defined.
- **Direction:** In addition to the **Vertical to bounding surface** setting, the **Request alignment** option can be used to customise the position of the local coordinate system.
- **Bore:** Determines whether the nozzle geometry is deducted from the vessel wall.

This makes the installation of nozzles much more intuitive and faster, as all relevant parameters can be defined in a single step.

## Automatic placement of guidelines: Minimum angle for elbows

Starting with HiCAD 31.0, the new option **Minimum elbow angle for AutoPlace parts** is available in the Configuration Editor under **Plant Engineering > Layout plan**. This option allows you to specify the minimum angle at which guidelines are automatically provided with elbows during AutoPlace. Smaller angles are instead implemented with a mitre cut.



## Write IFC class when installing pipe parts


Starting with HiCAD 31.0, the HiCAD attribute **IfcType** is automatically assigned an IFC class when inserting pipe parts. The assignment of component types to the corresponding IFC classes can be adjusted via the file *Install/PlantParts/IfcConfig/PartTypeIfcClassMapping.txt*.

It is also possible to assign an IFC class directly to a VAA/PAA. To do this, the HELiOS attribute **IFC\_CLASS** is added to your HELiOS database when you run the **Update the HELiOS database for Plant Engineering** function via **DBPlantDataImport.exe**.

## Isometry and pipe spool drawing

### Apply in the isometry update dialogue


The new **Apply** button has been added to the **Isometry/Pipe spool drawing display and update** function dialogue window. This allows changes to be applied directly while the dialogue window remains open. This means that several elements can be updated, removed or added one after the other without having to restart the dialogue window each time.



## Resolve 45° inclines in isometry



Sections of pipelines that run at a 45° angle to a coordinate axis can be problematic in isometric projection, as they can obscure other pipeline sections.

For this purpose, a new option has been added to the Isometry and pipe spool drawing settings, which can be found in the **Pipe shortening** tab. When creating the isometry, the affected pipe section can now be rotated by the specified angle using **Resolve non-parallel overlaps** so that hidden sections become visible.




### Example:

The following example shows a pipeline with overlaps in **Isometric projection 3**, where hidden sections are made visible in the next step by resolving them.



The following illustration shows the same line twice: once without resolving and once with resolving activated and a rotation angle of **4.00**.



(1) Example without resolving, (2) Example with resolving activated.



#### Please note:

- The function is not limited to pipeline constructions with 45° angles, but resolves all overlaps of non-parallel pipes.
- The rotation angle is limited to the range **-10.00** to **+10.00**; the prefix determines the direction of rotation.

### Pipe angle only for angles not equal to 90°

By default, the **%PIPE\_ANGLE** attribute outputs the angle of elbows and bends in bent pipelines.

The attribute **%PIPE\_NO\_90\_ANGLE** has been introduced as a further addition. It only outputs a value if the respective pipe angle deviates from 90°. This allows only deviating angles to be specifically marked in drawings, while 90° pipe angles remain unmarked.

### Link views generated in the pipe spool drawing


Previously, the different views (e.g. front view, top view, side view) of a pipe in the **Pipe spool drawing** were not linked to each other.

Starting with HiCAD 31.0, all views are now automatically linked to the main view, so that changes to this view are directly applied to the other views. This simplifies the subsequent processing of the drawing.

## Symbol Editor: Structure database symbols according to classification



The **Symbol Editor**, located under **Plant Engineering > Part Tools > Exchange > Symbol Editor**, is used to edit symbolic representations. Starting with HiCAD 31.0, the symbols in the **Database** branch are now automatically displayed in subdirectories according to their classification. This improves the clarity of the dialogue.




The main directory **Database** continues to display all symbolic representations in a list.



### Isometry dialogue: Behaviour of options revised

The **Link document** and **Create new drawing** options in the Isometry dialogue are now saved directly to the pipeline. This means that the behaviour is more closely aligned with the actual specifications on the pipeline.

In the Configuration Editor under **Plant Engineering > Isometry and Pipe Spool Drawing** you can still store default values for **Create document links** and **Always generate pipe spool drawing in new drawing file**. These are applied automatically if no specific information is available for the pipeline.



It is currently not possible to use both options in combination.



## HELIOS API


### Document number via article master

Four additional virtual article attributes have been introduced that display the document number of a document linked to an article. The attributes differ only in terms of which HELIOS link is used to determine the linked document.

Attribute name	Displayed name	Viewed link
VA_LINKED_SZA	Linked drawing	Bauteil-Konstruktion
VA_LINKED_SPL	Linked pipe spool drawing	Pipeline-Spool
VA_LINKED_ISO	Linked isometry	Pipeline-Isometry
VA_LINKED_LAY	Linked layout plan	Pipeline-Layoutplan

If several documents are linked, only the document number of the first document found is displayed.

The new attributes are available in the dialogue window for annotation tags:



Alternatively, you can also use %DBAT(VA\_LINKED\_...).

# Catalogue Editor

## Major Release

### Catalogue extension: Hollow profile DIN EN 10305-3

The hollow profile **DIN EN 10305-5** has been withdrawn and replaced by **DIN EN 10305-3**. This hollow profile has been divided into two types and can be found in tables **DIN EN 10305-3 Q** and **DIN EN 10305-3 R** at **Semi-finished products > Beams+Profiles > Hollow profiles**.

CATEditor - [ Catalogues\Semi-finished products\Beams+Profiles\Hollow profiles\EN 10305-3 Q ] [ C:\HiCAD\Kataloge ] [ Version: 31.0.0.39 ] [ Zuletzt geprüft: 03.06.2025 ]

File Edit View Extras HELIOS Settings 2 ISD

Factory standards  
Fasteners  
Materials  
Plant Engineering  
Processings, general  
Semi-finished products  
Plates  
Gratings  
Wood  
Cold rolled sections  
Beams+Profiles  
Reinforced steel  
Flat steel  
Hollow profiles  
DIN 2395-1 R  
DIN 2395-1 Q  
HQ-warm (DIN EN 10210-2 HQ)  
HR-warm (DIN EN 10210-2 HR)  
HQ-cold (DIN EN 10219-2 HQ)  
HR-cold (DIN EN 10219-2 HR)  
**DIN EN 10305-3 Q**  
**DIN EN 10305-3 R**  
DIN EN 10305-5  
HP Q  
HP R  
I - Beams  
Crane rails  
L - Beams  
Round steel  
Hexagon steel


ID	MOD	STATUS	Designation	Size	MATERIAL	OBERFL	TYPE	B	S	RI	RA	Weight	MANTELFL
1	1	▶	EN 10305-3 15x15x0.6	15x15x0.6	E155+A		E155+A	15	0.6	0.3	0.9	0.271	0.1153
2	2	▶	EN 10305-3 15x15x0.8	15x15x0.8	E155+A		E155+A	15	0.8	0.4	1.2	0.356	0.1137
3	3	▶	EN 10305-3 15x15x1	15x15x1	E155+A		E155+A	15	1	0.5	1.5	0.438	0.1121
4	4	▶	EN 10305-3 15x15x1.2	15x15x1.2	E155+A		E155+A	15	1.2	0.6	1.8	0.518	0.1105
5	5	▶	EN 10305-3 15x15x1.5	15x15x1.5	E155+A		E155+A	15	1.5	0.75	2.25	0.632	0.1082
6	6	▶	EN 10305-3 15x15x1.8	15x15x1.8	E155+A		E155+A	15	1.8	0.9	2.7	0.741	0.1058
7	7	▶	EN 10305-3 15x15x2	15x15x2	E155+A		E155+A	15	2	1	3	0.81	0.1042
8	8	▶	EN 10305-3 15x15x2.2	15x15x2.2	E155+A		E155+A	15	2.2	1.1	3.3	0.876	0.1026
9	9	▶	EN 10305-3 20x20x0.6	20x20x0.6	E155+A		E155+A	20	0.6	0.3	0.9	0.365	0.1553
10	10	▶	EN 10305-3 20x20x0.8	20x20x0.8	E155+A		E155+A	20	0.8	0.4	1.2	0.481	0.1537
11	11	▶	EN 10305-3 20x20x1	20x20x1	E155+A		E155+A	20	1	0.5	1.5	0.595	0.1522
12	12	▶	EN 10305-3 20x20x1.2	20x20x1.2	E155+A		E155+A	20	1.2	0.6	1.8	0.706	0.1506
13	13	▶	EN 10305-3 20x20x1.5	20x20x1.5	E155+A		E155+A	20	1.5	0.75	2.25	0.868	0.1482
14	14	▶	EN 10305-3 20x20x1.8	20x20x1.8	E155+A		E155+A	20	1.8	0.9	2.7	1.02	0.1459
15	15	▶	EN 10305-3 20x20x2	20x20x2	E155+A		E155+A	20	2	1	3	1.12	0.1443
16	16	▶	EN 10305-3 20x20x2.2	20x20x2.2	E155+A		E155+A	20	2.2	1.1	3.3	1.22	0.1427
17	17	▶	EN 10305-3 25x25x0.6	25x25x0.6	E155+A		E155+A	25	0.6	0.3	0.9	0.459	0.1953
18	18	▶	EN 10305-3 25x25x0.8	25x25x0.8	E155+A		E155+A	25	0.8	0.4	1.2	0.607	0.1938
19	19	▶	EN 10305-3 25x25x1	25x25x1	E155+A		E155+A	25	1	0.5	1.5	0.752	0.1922
20	20	▶	EN 10305-3 25x25x1.2	25x25x1.2	E155+A		E155+A	25	1.2	0.6	1.8	0.894	0.1906
21	21	▶	EN 10305-3 25x25x1.5	25x25x1.5	E155+A		E155+A	25	1.5	0.75	2.25	1.1	0.1883
22	22	▶	EN 10305-3 25x25x1.8	25x25x1.8	E155+A		E155+A	25	1.8	0.9	2.7	1.31	0.1859
23	23	▶	EN 10305-3 25x25x2	25x25x2	E155+A		E155+A	25	2	1	3	1.44	0.1844
24	24	▶	EN 10305-3 25x25x2.2	25x25x2.2	E155+A		E155+A	25	2.2	1.1	3.3	1.57	0.1828
25	25	▶	EN 10305-3 30x30x0.6	30x30x0.6	E155+A		E155+A	30	0.6	0.3	0.9	0.553	0.2353

Ready

0 3564 13:55:35 1091 NUM

## Catalogue extension: Washers DIN 6319 C and DIN 6319 D

The standard **DIN 6319** has been withdrawn without replacement, but the spherical washers and conical sockets will continue to be used. Three tables from DIN 6319 have been added. These are **DIN 6319 Form C (ball washer)**, **DIN 6319 Form D (conical socket)** and **DIN 6319 Form G (conical socket)**. You can find these three tables at **Fasteners > Washers > Washers**.



## US Hollow Profiles AISC HSS RE (imperial)

Two new tables have been created at **Factory standards > User-defined semi-finished products > User-defined profiles > Hollow profiles > Atlas Tube** and a new table at **... > Hollow profiles > Sugar Steel**. These contain Rectangular HSS, Square HSS and Square Tubing.

CATEditor - [ Catalogues\Factory standards\User-defined semi-finished products\User-defined profiles\Hollow profiles\Sugar Steel\Square Tubing (inch) ] [ C:\HiCAD\Kataloge... ]

File Edit View Extras HELIOS

Factory standards

- User-defined building materials
- User-defined processings
- User settings
- User-defined moulding tools
- User-defined dish ends
- User-defined semi-finished products
  - User-defined profiles
    - Atlas Tube
      - Rectangular HSS (inch)
      - Square HSS (inch)
    - Sugar Steel
    - Hollow profiles
      - Square Tubing (inch)
  - User-defined textures
  - User-defined fasteners
  - User-defined materials
  - User-defined cylinders
  - Series
  - Bend zone tooling
  - Manufacturability check
  - Railing
  - Glass dimensionings
  - Glass panes
  - IFC interface
  - Sheets


ID	MOE	STATUS	BZ	SIZE	MATERIAL	OBERFL	TYPE	B	S	RI	RA	G
1	1		1/2x1/2x18GA.	1/2x1/2x18GA.	ASTM A500 Grade C		ASTM A500 Grade C	0.5	0.049	0.049	0.098	0.3
2	2		3/4x3/4x18GA.	3/4x3/4x18GA.	ASTM A500 Grade C		ASTM A500 Grade C	0.75	0.049	0.049	0.098	0.4
3	3		1 1/2x1 1/2x16 G	1 1/2x1 1/2x16 G	ASTM A500 Grade C		ASTM A500 Grade C	1.5	0.065	0.065	0.13	1
4	4		1 1/4x1 1/4x16 G	1 1/4x1 1/4x16 G	ASTM A500 Grade C		ASTM A500 Grade C	1.25	0.065	0.065	0.13	1
5	5		1 3/4x1 3/4x16 G	1 3/4x1 3/4x16 G	ASTM A500 Grade C		ASTM A500 Grade C	1.75	0.065	0.065	0.13	0.3
6	6		1/2x1/2x16GA.	1/2x1/2x16GA.	ASTM A500 Grade C		ASTM A500 Grade C	0.5	0.065	0.065	0.13	0.3
7	7		1x1x16GA.	1x1x16GA.	ASTM A500 Grade C		ASTM A500 Grade C	1	0.065	0.065	0.13	0
8	8		2x2x16GA.	2x2x16GA.	ASTM A500 Grade C		ASTM A500 Grade C	2	0.065	0.065	0.13	1
9	9		3/4x3/4x16GA.	3/4x3/4x16GA.	ASTM A500 Grade C		ASTM A500 Grade C	0.75	0.065	0.065	0.13	0.6
10	10		1 1/2x1 1/2x14 G	1 1/2x1 1/2x14 G	ASTM A500 Grade C		ASTM A500 Grade C	1.5	0.083	0.083	0.166	1
11	11		1 1/4x1 1/4x14 G	1 1/4x1 1/4x14 G	ASTM A500 Grade C		ASTM A500 Grade C	1.25	0.083	0.083	0.166	1
12	12		1 3/4x1 3/4x14 G	1 3/4x1 3/4x14 G	ASTM A500 Grade C		ASTM A500 Grade C	1.75	0.083	0.083	0.166	1
13	13		1x1x14GA.	1x1x14GA.	ASTM A500 Grade C		ASTM A500 Grade C	1	0.083	0.083	0.166	1
14	14		2 1/2x2 1/2x14 G	2 1/2x2 1/2x14 G	ASTM A500 Grade C		ASTM A500 Grade C	2.5	0.083	0.083	0.166	2
15	15		2 1/4x2 1/4x14 G	2 1/4x2 1/4x14 G	ASTM A500 Grade C		ASTM A500 Grade C	2.25	0.083	0.083	0.166	2
16	16		2x2x14GA.	2x2x14GA.	ASTM A500 Grade C		ASTM A500 Grade C	2	0.083	0.083	0.166	2
17	17		3/4x3/4x14GA.	3/4x3/4x14GA.	ASTM A500 Grade C		ASTM A500 Grade C	0.75	0.083	0.083	0.166	0.7
18	18		3x3x14GA.	3x3x14GA.	ASTM A500 Grade C		ASTM A500 Grade C	3	0.083	0.083	0.166	3
19	19		1 1/2x1 1/2x11 G	1 1/2x1 1/2x11 G	ASTM A500 Grade C		ASTM A500 Grade C	1.5	0.12	0.12	0.24	2
20	20		1 1/4x1 1/4x11 G	1 1/4x1 1/4x11 G	ASTM A500 Grade C		ASTM A500 Grade C	1.25	0.12	0.12	0.24	1
21	21		1 3/4x1 3/4x11 G	1 3/4x1 3/4x11 G	ASTM A500 Grade C		ASTM A500 Grade C	1.75	0.12	0.12	0.24	1
22	22		1x1x11GA.	1x1x11GA.	ASTM A500 Grade C		ASTM A500 Grade C	1	0.12	0.12	0.24	1
23	23		2 1/2x2 1/2x11 G	2 1/2x2 1/2x11 G	ASTM A500 Grade C		ASTM A500 Grade C	2.5	0.12	0.12	0.24	2
24	24		2 1/4x2 1/4x11 G	2 1/4x2 1/4x11 G	ASTM A500 Grade C		ASTM A500 Grade C	2.25	0.12	0.12	0.24	2
25	25		2x2x11GA.	2x2x11GA.	ASTM A500 Grade C		ASTM A500 Grade C	2	0.12	0.12	0.24	2

Ready

0 113 14:00:31 521201382 NUM


## Self-drilling screw JT3-FR-2H-4.8

The table **JT3-FR-2H** has been added to **Factory standards > User-defined fasteners > User-defined bolts+screws > EJOT**. Here you will find the screw of the same name.



## Alias name Flutz profiles renamed to Flutz aluminium profiles

Due to the confusion caused by the alias name **Flutz** profiles, this has been changed to Flutz aluminium profiles. They can be found at **Factory standards > Factory beams > FLUTZ aluminium profiles**.





## Catalogue extension: EJOT self-drilling screws without sealing washers

The JT3-6-5.5 screw is also available from EJOT without a sealing washer. These screws have been added to the catalogue. You can find these screws at **Factory standards > User-defined fasteners > User-defined bolts+screws > EJOT > JT3-6**.

CATEditor - [ Catalogues\Factory standards\User-defined fasteners\User-defined bolts+screws\Ejot\JT3-6 ] [ C:\HiCAD\Kataloge ] [ Version: 31.0.0.72 ]

File Edit View

Factory standards

- User-defined building materials
- User-defined processings
- User settings
- User-defined moulding tools
- User-defined semi-finished products
- User-defined textures
- User-defined fasteners
  - User-defined anchors
  - User-defined studs
  - User-defined dowels
  - User-defined sockets
  - User-defined rivets
  - User-defined elbows
  - User-defined bolts+screws
    - ALUCOBOND
    - User-defined clinch studs
    - Ejot
      - JA3-LT
      - JF3
      - JF3-LT
      - JF6
      - JT3-12
      - JT3-2
      - JT3-6
      - JT3-6
      - JT3-FR-2H


ID	AOE	STATUS	Designation	ARTICLE	Size	MATERIAL	OBERFL	TYPE	TYP	Thread	DN	P	LN	SW	K
1	38		JT3-6-5,5x25	738030630	ST5.5x25	A2		A2	1	ST5.5	5.5	1.8	25	8	5.3
2	39		JT3-6-5,5x30	738030730	ST5.5x30	A2		A2	1	ST5.5	5.5	1.8	30	8	5.3
3	40		JT3-6-5,5x35	738030830	ST5.5x35	A2		A2	1	ST5.5	5.5	1.8	35	8	5.3
4	41		JT3-6-5,5x50	738030930	ST5.5x50	A2		A2	1	ST5.5	5.5	1.8	50	8	5.3
5	42		JT3-6-5,5x70	738038330	ST5.5x70	A2		A2	1	ST5.5	5.5	1.8	70	8	5.3
6	43		JT3-6-5,5x90	738038430	ST5.5x90	A2		A2	1	ST5.5	5.5	1.8	90	8	5.3
7	44		JT3-6-5,5x110	738038530	ST5.5x110	A2		A2	1	ST5.5	5.5	1.8	110	8	5.3
8	45		JT3-6-5,5x130	738038630	ST5.5x130	A2		A2	1	ST5.5	5.5	1.8	130	8	5.3
9	46		JT3-6-5,5x150	738054830	ST5.5x150	A2		A2	1	ST5.5	5.5	1.8	150	8	5.3
10	47		JT3-6-5,5x170	738054930	ST5.5x170	A2		A2	1	ST5.5	5.5	1.8	170	8	5.3
11	48		JT3-6-5,5x190	738055030	ST5.5x190	A2		A2	1	ST5.5	5.5	1.8	190	8	5.3
12	1		JT3-6-5,5x25-E14	357220936	ST5.5x25	A2		A2-E14	1	ST5.5	5.5	1.8	25	8	5.3
13	2		JT3-6-5,5x30-E14	357237736	ST5.5x30	A2		A2-E14	1	ST5.5	5.5	1.8	30	8	5.3
14	3		JT3-6-5,5x35-E14	357257736	ST5.5x35	A2		A2-E14	1	ST5.5	5.5	1.8	35	8	5.3
15	4		JT3-6-5,5x25-E16	357221136	ST5.5x25	A2		A2-E16	1	ST5.5	5.5	1.8	25	8	5.3
16	5		JT3-6-5,5x30-E16	357231136	ST5.5x30	A2		A2-E16	1	ST5.5	5.5	1.8	30	8	5.3
17	6		JT3-6-5,5x35-E16	357251136	ST5.5x35	A2		A2-E16	1	ST5.5	5.5	1.8	35	8	5.3
18	7		JT3-6-5,5x50-E16	359281136	ST5.5x50	A2		A2-E16	1	ST5.5	5.5	1.8	50	8	5.3
19	8		JT3-6-5,5x70-E16	359391136	ST5.5x70	A2		A2-E16	1	ST5.5	5.5	1.8	70	8	5.3
20	9		JT3-6-5,5x90-E16	359611136	ST5.5x90	A2		A2-E16	1	ST5.5	5.5	1.8	90	8	5.3
21	10		JT3-6-5,5x110-E16	359621136	ST5.5x110	A2		A2-E16	1	ST5.5	5.5	1.8	110	8	5.3
22	11		JT3-6-5,5x130-E16	359631136	ST5.5x130	A2		A2-E16	1	ST5.5	5.5	1.8	130	8	5.3
23	12		JT3-6-5,5x150-E16	359641136	ST5.5x150	A2		A2-E16	1	ST5.5	5.5	1.8	150	8	5.3
24	13		JT3-6-5,5x170-E16	359651136	ST5.5x170	A2		A2-E16	1	ST5.5	5.5	1.8	170	8	5.3
25	14		JT3-6-5,5x190-E16	359661136	ST5.5x190	A2		A2-E16	1	ST5.5	5.5	1.8	190	8	5.3

Ready

0 48 10:58:18 521201188 NUM

## Catalogue extension: Bore patterns and Punching tools

In the catalogues **Factory standards > Bore patterns** and **Factory standards > Punching tools** the tables die Tabellen **Rectangle (filleted)** and **Keyhole** have been added.





## Implementation of Halfen HM Mounting rails and Halfen HS special bolts


The data for Halfen HM mounting rails and Halfen HS special bolts have been added to the Catalogue Editor. You can find them at **Factory standards > Series > Roof Wall Facade > Lightweight profiles > HALFEN > HM Mounting rails** and at **Factory standards > User-defined fasteners > User-defined bolts+screws > HALFEN > HALFEN HS**.

CATEditor - [ Catalogues\Factory standards\User-defined fasteners\User-defined bolts+screws\HALFEN\HALFEN HS ] [ C:\HiCAD\Kataloge ] [ Version: 31.1.0.138 ]

File View Extras HELIOS Settings 2 ISD

Halfen

- User-defined nuts
- User-defined rivets
- User-defined elbows
- User-defined bolts+screws
- ALUCOBOND
- User-defined clinch studs
- Ejot
- Eternit
- Fastenal
- HALFEN
  - HALFEN HS**
  - HP-1
  - HBI
  - SENCO
  - SFS
  - Templates
  - Hexagon socket cheese head facad



ID	MOE	STATUS	BZ	SIZE	MATERIAL	OBERFL	TYPE	SYSTEM	GEW	DN	P
1	1	▶	HS 28/15 M10x20 FV4.6	HS 28/15 M10x20	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 28/15	M10	10	1.
2	2	▶	HS 28/15 M10x30 FV4.6	HS 28/15 M10x30	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 28/15	M10	10	1.
3	3	▶	HS 28/15 M10x50 FV4.6	HS 28/15 M10x50	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 28/15	M10	10	1.
4	4	▶	HS 38/17 M10x30 FV4.6	HS 38/17 M10x30	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M10	10	1.
5	5	▶	HS 38/17 M12x30 FV4.6	HS 38/17 M12x30	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M12	12	1.7
6	6	▶	HS 38/17 M12x50 FV4.6	HS 38/17 M12x50	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M12	12	1.7
7	7	▶	HS 38/17 M16x30 FV4.6	HS 38/17 M16x30	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M16	16	
8	8	▶	HS 38/17 M16x40 FV4.6	HS 38/17 M16x40	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M16	16	
9	9	▶	HS 38/17 M16x50 FV4.6	HS 38/17 M16x50	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M16	16	
10	10	▶	HS 38/17 M16x80 FV4.6	HS 38/17 M16x80	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M16	16	
11	11	▶	HS 38/17 M16x100 FV4.6	HS 38/17 M16x100	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 38/17	M16	16	
12	12	▶	HS 40/22 M10x20 FV4.6	HS 40/22 M10x20	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
13	13	▶	HS 40/22 M10x30 FV4.6	HS 40/22 M10x30	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
14	14	▶	HS 40/22 M10x40 FV4.6	HS 40/22 M10x40	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
15	15	▶	HS 40/22 M10x50 FV4.6	HS 40/22 M10x50	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
16	16	▶	HS 40/22 M10x60 FV4.6	HS 40/22 M10x60	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
17	17	▶	HS 40/22 M10x80 FV4.6	HS 40/22 M10x80	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.
18	18	▶	HS 40/22 M10x100 FV4.6	HS 40/22 M10x100	4.6	Hot-dip galvanizec	4.6 Hot-dip galvanizec	HS 40/22	M10	10	1.


Ready 1: ID 0 358 09:40:18 521201388 NUM

CATEditor - [ Catalogues\Factory standards\Series\Roof Wall Facade\Lightweight profiles\HALFEN\HM mounting rails ] [ C:\HiCAD\Kataloge ] [ Version: 31.1.0.138 ]

File Edit View Extras HELIOS Settings

Halfen

- User-defined semi-finished products
- User-defined textures
- User-defined fasteners
- User-defined materials
- User-defined cylinders
- Series
  - Roof Wall Facade
    - Moulded parts
    - Lightweight profiles
      - User-defined profiles
      - Arcelormittal
      - Bruchsa
      - Fischer
      - HALFEN
        - HM mounting rails**
        - Metechno
        - Münker



ID	MOE	STATUS	BZ	NAME	ICON	MATERIAL	SYSTEM	H
1	1	▶	HM 20/12-A2-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 20/12	20
2	2	▶	HM 28/15-A2-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 28/15	28
3	3	▶	HM 38/17-A2-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 38/17	38
4	4	▶	HM 40/25-A2-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 40/25	39.5
5	5	▶	HM 41/41-A2-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 41/41	41
6	6	▶	HM 49/30-A2-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A2	HM 49/30	50
7	7	▶	HM 28/15-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 28/15	28
8	8	▶	HM 28/28-A4-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 28/28	27
9	9	▶	HM 36/36-A4-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 36/36	36
10	10	▶	HM 38/17-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 38/17	38
11	11	▶	HM 40/22-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM_1.KRA	HM_1	A4	HM 40/22	39.5
12	12	▶	HM 40/25-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 40/25	39.5
13	13	▶	HM 41/22-A4-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 41/22	41
14	14	▶	HM 41/41-A4-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 41/41	41
15	15	▶	HM 49/30-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 49/30	50
16	16	▶	HM 50/30-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM_1.KRA	HM_1	A4	HM 50/30	49
17	17	▶	HM 50/40-A4-6000	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM.KRA	HM	A4	HM 50/40	49
18	18	▶	HM 52/34-A4-6070	Baureihen\ Dach Wand Fassade\Leichtbauprofile\HALFEN\HM_1.KRA	HM_1	A4	HM 52/34	52.5

Ready 1: ID 1 68 09:39:10 521201389 NUM

## Bill of Materials / Report Manager

### Discontinuation of the Report Manager Professional


The additional functionality of Report Manager Professional has been integrated into the Report Manager.


### Discontinuation of the "old" Report Manager

From HELiOS 2024 onwards, the "old" Report Manager, i.e. the Report Manager up to 2022, will no longer be delivered with a standalone installation of the HELiOS Desktop. In a HiCAD/HELiOS installation or a HELiOS update of HiCAD, however, the "old" Report Manager is still included. From HiCAD 2025 onwards, only the "new" Report Manager as of 2023 will be supported.

## Major Release

### Search by alias name

In the **Column settings**  of the Report Manager, you can search for attributes. The attribute name and description were taken into account. Starting with HiCAD 2026, you can also search for the alias name for the attributes.



### Fixed length for Bar - Summary

In practice, beams and profiles with a fixed length and cutting angle (e.g. angle profile with a fixed length of 300 mm and a cutting angle of 45 degrees) are often ordered. In the **Bar - Summary** list, all beams and profiles with the same fixed length were previously summarised without taking the cutting angle into account. This meant that distinguishing features for ordering were lost. From HiCAD 2026 onwards, the cutting angle will also be taken into account when summarising beams and profiles in addition to the fixed length.

## BOM-relevance of auxiliary and environment parts


Auxiliary and surrounding parts are often included in the drawing, but should not normally appear in BOMs.

If the BOM-relevance of already itemised parts is changed retrospectively, this can lead to inconsistencies in the item numbers and texts.

For this reason, from HiCAD 2026 onwards, the procedure of creating auxiliary and surrounding parts outside the main assembly is supported. The following changes have been made for this purpose:



In the **Itemisation with options 1...n** dialogue window, the **Only within main assembly** option has been added to the **Numbering** section of the **General** tab.

The **Only consider parts within the main assembly** checkbox has been added to the **General** section of the **Bill of materials**  dialogue window.

Two default settings have been adjusted in the Configuration Editor:

- The referencing setting for the **BOM-relevant** attribute at **System settings > Attribute management > Attributes** has been changed from "Do not transfer" to **Standard behaviour**.
- At **Modelling > Change part structure**, the **Move parts out of main assembly** checkbox is now enabled by default for all industries. Previously, this was only the case for Steel Engineering.

# Configuration Management

## Major Release

### Apply attributes without restarting

Each time a function is started in HiCAD that offers attribute selection, the attribute list is now checked to see if it is up to date and will be reloaded if changes have been made. This concerns


- the **Attributes mask**
- the **Text Editor** and
- the **P+ID attribute assignment dialogue**.

The **ICN Properties window** is updated when the part is changed.

During the update, the system first checks whether the HiCAD.cfgdb has been changed. If the ConfigDB has been changed, it is reloaded.

### Display of point clouds


The settings for the graphical representation of the point cloud have been expanded. You now have the option of sig-

nificantly improving the depth and realistic representation using the **Settings**  function for point clouds. The options set for the representation of point clouds apply to all point clouds in the design and are saved in the design when you save it.

The default settings for new drawings can be found in the Configuration Editor at **Drawing > Views > Display of point cloud**.

### Revised Show/hide elements in view dialogue


In the Configuration Editor, at **Drawings > Views**, the "Hiding and overlapping of edges" area has been renamed to **Show/hide elements**. Here you will find the default settings for the dialogue window of the HiCAD function **Show/hide**

**elements in view**  from the **Views** menu bar. Most of the names in this area have been changed to match the names in the dialogue. This also applies to the names found at **System settings > Visualisation > Views > Insertion view**.

### Switch drawing

Due to the expansion of the Switch drawing windowAD, the parameters Switch drawing window, Width and Switch drawing window, Height (System settings > Graphic) are no longer required. You can now adjust the thumbnail windows using the Ctrl key and the middle mouse button.

### Reference symbol

Since the **Reference symbol**  can be used as a reference point for both form and positional tolerances and for the surface symbol, a separate function has been created in the menu bar. In this context, the texts of the default

settings in the Configuration Editor at **Drawing > Annotations > Form/Positional tolerances** have also been aligned with those in the function dialogue.

- Line colour > **Symbol colour**
- Base point symbol, Tolerance > **Reference line end of tolerance symbol**
- Length of base point symbol, Tolerance > **Length of reference line end of tolerance symbol**
- Height of base point symbol, Tolerance > **Width of reference line end of tolerance symbol**
- Base point symbol of reference element > **Reference line end of reference symbol**
- Length of base point symbol of reference element > **Length of reference line end of reference symbol**
- Height of base point symbol of reference element > **Width of reference line end of reference symbol**

Furthermore, the following settings have been added::

- **Select leader line end automatically** and
- **Combine identical features**

## Annotation of countersunk holes

You can select the standard for the annotation of countersunk and blind holes in the Configuration Editor at **System settings > Annotations > Part annotation > Standard for annotation of countersunk holes**. The setting is saved together with the drawing. For older drawings in which this setting has not yet been saved, the value is set to the standard designation according to DIN ISO 15876.



In the **3-D Dimensioning = Text** menu bar, you will find the new function **Settings for annotations** in the **Text** function group. This allows you to change the annotation of the drawing. After a change, all tags are drawn so that the current standard is used everywhere.

## BOM-relevance of auxiliary and environment parts

Auxiliary and surrounding parts are often included in the drawing, but should not normally appear in BOMs. If the BOM-relevance of already itemised parts is changed subsequently, this can lead to inconsistencies in the item numbers and texts.

For this reason, from HiCAD 2026 onwards, the procedure of creating auxiliary and surrounding parts outside the main assembly is supported. Two default settings have been adjusted in the Configuration Editor:

- The referencing setting for the **BOM-relevant** attribute at **System settings > Attribute management > Attributes** has been changed from "Do not transfer" to **Standard behaviour**.
- At **Modelling > Change part structure**, the Move parts out of main assembly checkbox is now enabled by default for all industries. Previously, this was only the case for Steel Engineering.

## View orientation during drawing derivation

When deriving drawings of assemblies whose part orientation was not determined manually but via the part coordinate system of the main part, the front view was rotated by 90 degrees compared to the front view determined by the part orientation. This behaviour has been corrected in HiCAD 2026.

In the Configuration Editor, at **Compatibility > Automatic drawing derivation**, the parameter **View orientation of general parts and assemblies** has been added to maintain the old behaviour for new drawings.


## Referenced parts with HELiOS article master

The following parameters at **System settings > Referencing** have been revised:

- **Lock parts against processing if HELiOS article master is locked**  
If parts are to be locked against processing when the assigned article master is reserved or locked, then activate the checkbox ☒.
- **Reserve the assigned article master when unsaved changes to a part are made**  
This parameter was called "Lock parts for other users via HELiOS article master" in HiCAD 2025.  
If the assigned HELiOS article master of a part is to be reserved automatically as soon as geometric changes are made, select **Yes**.

## Automatic or manual calculation of attributes

Depending on the settings in the Configuration Editor (**System settings > Attribute management > Attribute calculation**), certain attributes in HiCAD, such as Weight, Surface area, Volume, Length, and Width, can be calculated automatically. Previously, this automatic calculation setting in HiCAD could be disabled by activating the %WFIX attribute via the **Weight fixed** checkbox in the Part attributes mask. The %WFIX attribute and the checkbox have been removed. Instead, you can now set individually for each attribute in the part attribute mask for each part

whether it should be calculated automatically or entered manually . To do this, right-click on the input field in the Part attributes mask or in the Properties window of the ICN and select **Set attribute manually**.

When loading old designs in HiCAD 2026, the %WFIX attribute is still evaluated and affected part attributes are set to **Set attribute manually**. In configuration management, the %WFIX attribute then becomes an internal system attribute.

## Attributes for Steel Engineering

To increase user-friendliness, the descriptions of the attributes for Steel Engineering have been expanded.

## AutoPlace parts on guidelines: Minimum angle for elbows

Starting with HiCAD 31.0, the new option **Minimum elbow angle for AutoPlace parts** is available in the Configuration Editor at **Plant Engineering > Layout plan**. This option allows you to specify the minimum angle at which leading edges are automatically fitted with pipe elbows during auto-placement. Smaller angles are instead implemented with a mitre cut..

## PRODUKTEDITORKONFIG.DAT removed

The settings from the PRODUKTEDITORKONFIG.DAT file are no longer relevant for HiCAD and HELIOS. The file is therefore no longer available.





# Notes on HELiOS Updates

## Microsoft SQL Server

The SQL Server Native Client (often abbreviated to SNAC) has been removed by Microsoft from SQL Server 2022 (16.x) and SQL Server Management Studio 19 (SSMS). It is recommended to use the latest version of the Microsoft ODBC Driver for SQL Server instead.

Further information can be found on the [Microsoft](#) website or in the installation instructions for [Microsoft SQL Server 2022](#).

## HELiOS Workspaces: Conversion of the system directories

When updating from an older version to HELiOS 2025 (Version 30.0.0) or higher, please note that the directory structure will change. Since an automated migration is not possible, all users have to check out all data and empty their workspaces before installing the update to avoid data loss.

In previous versions, the workspaces were located at %localappdata%. This meant that different workspaces could be located on one system. To prevent this, the update to HELiOS 2025 will move the workspaces to the **%programdata%** directory.

Checked-out files are then stored at **%programdata%\ISD Software und Systeme\HELiOS Workspace\(...)\*\** (\*plus Location ID and User ID). The workspace databases are stored version-dependently at **%programdata%\ISD Software und Systeme\HELiOS <Version>\Location-ID\**.

## Notes on update installations

For an update installation of a HELiOS version older than HELiOS 2020 (version 2500), a central update of the supplied HELiOS database must be carried out..

Since conflict may occur during the update process in case of inconsistent data stocks, you should do the following:

- **Data backup before updating**

Make sure that a data backup was made before carrying out the update of your HELiOS database.

For the backup, either use the HELiOS Database Creator (further information can be found in the Installation Notes) or your SQL Server Application.

In case of any questions, or if you need any help with regard to your customized system architecture , contact the ISD Hotline.

- **Log file for update**

If any conflicts occur during the update, these will be recorded in the log file **HeliosDbUpdate.txt** (in the system path **%appdata%\ISD Software und Systeme\HeliosDbUpdate\**).

Have this file ready when contacting the ISD Hotline in case of an unsuccessful update, so that they can help you solve the problem and make a successful update.

- **New mask format**

Please read all notes on the new mask format introduced with HELiOS 2020 !

- **MultiCAD interfaces**

If you are working with a multi-CAD interface (e.g. the HELiOS-Inventor interface), please note that before installing an update of an older version to HELiOS 2020 (Version 2500) or higher, some adjustments may have to be made before the update.

In this case, please contact the Consulting department of the ISD Group.


# HELiOS Desktop


## Major Release

### Full-text search


HELiOS 2026 offers the option of integrating a **Full-text search** function into your PDM system.

If you have installed the full-text search on the server and client side, you can also search for and find HELiOS documents of certain file types (text, PDF, emails) using content keywords.

For this purpose the new **Document full-text search** dialogue window is available via **Find > Full-text search > Documents** , and you can also integrate the full-text search into the "regular" document search.




With the new virtual database attribute **Content relevance**, the search results can then also be sorted according to their percentage relevance to the full-text search result.



In the **Admin Tools** ribbon of HELIOS, you will find the function call **Update search index**, which you can use to initially index your HELIOS inventory data of the supported formats for full-text search and to trigger subsequent indexing.

The full-text search is also available in the **HELIOS Internet Server** user interface.



## Model structure and Document references

### Document reference structure up-to-dateness

A new attribute is available for document result lists:


**Document reference structure up-to-dateness (UI\_ReferenceTreesOutdated)** indicates for a document whether a newer version of the documents referenced by the document is available.

This means that the recursive structure of the file references is considered, regardless of the document index.

For HiCAD files, for example, this means that the file version (internal KRA version number) of the referenced document has changed since the referencing document was last saved.

When HELiOS is newly installed, the new attribute **Document reference structure up-to-dateness (UI\_ReferenceTreesOutdated)** is shown by default.

After update installations, it is available in the attribute configuration for document result lists.



For current documents, the column entry remains empty. For outdated documents, a triangular warning symbol is displayed:

Articles

Objects

Documents

Standard

Document number	Ind	Wo	Designation	Document type	Creation date	Created by	File changed on	File extension
DN-000245			Word Document	Office Document	19.03.2025	Administrator	19.03.2025 14:31:36	.docx
DN-000246			Word Document	Office Document	19.03.2025	Administrator	19.03.2025 14:31:40	.docx
DN-000247			Draught	HiCAD Drawing	19.03.2025	Administrator	19.03.2025 14:32:13	.sza
DN-000001			Draught	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:55:56	.sza
DN-000002			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 15:58:42	.kra
DN-000003			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:55:59	.sza
DN-000004			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 16:12:23	.kra
DN-000005			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:02	.sza
DN-000006			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:04	.sza
DN-000007			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:06	.sza
DN-000008			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 17:19:59	.kra
DN-000009			Production drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:13	.sza
DN-000010			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 17:23:18	.kra
DN-000011			Production drawing	HiCAD Drawing	03.10.2006	Konstrukteur1	25.10.2006 09:48:15	.sza
DN-000012			3-D model	HiCAD Part/Variant	03.10.2006	Konstrukteur1	03.10.2006 13:30:26	.kra
DN-000013			Production drawing	HiCAD Drawing	03.10.2006	Konstrukteur1	24.10.2006 17:56:21	.sza
DN-000014			3-D model	HiCAD Part/Variant	03.10.2006	Konstrukteur1	03.10.2006 13:32:58	.kra
DN-000015			Production drawing	HiCAD Drawing	03.10.2006	Konstrukteur1	24.10.2006 17:56:24	.sza
DN-000016			3-D model	HiCAD Part/Variant	03.10.2006	Konstrukteur1	03.10.2006 13:35:43	.kra

If HELiOS cannot recognise a document structure, e.g. if the user has transferred a corresponding file to HELiOS using Drag & Drop or imported it into an existing document master, the reference up-to-dateness cannot be determined. In this case, a red question mark is displayed:

Articles

Objects


Documents

Standard

Document number	Ind	Wo	Designation	Document type	Creation date	Created by	File changed on	File extension	
DN-000001			Draught	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:55:56	.sza	
DN-000002			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 15:58:42	.kra	?
DN-000003			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:55:59	.sza	
DN-000004			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 16:12:23	.kra	?
DN-000005			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:02	.sza	
DN-000006			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:04	.sza	
DN-000007			Assembly drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:06	.sza	
DN-000008			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 17:19:59	.kra	?
DN-000009			Production drawing	HiCAD Drawing	02.10.2006	Konstrukteur1	24.10.2006 17:56:13	.sza	
DN-000010			3-D model	HiCAD Part/Variant	02.10.2006	Konstrukteur1	02.10.2006 17:23:18	.kra	?
DN-000011			Production drawing	HiCAD Drawing	03.10.2006	Konstrukteur1	25.10.2006 09:48:15	.sza	
DN-000012			3-D model	HiCAD Part/Variant	03.10.2006	Konstrukteur1	03.10.2006 13:30:26	.kra	?
DN-000013			Production drawing	HiCAD Drawing	03.10.2006	Konstrukteur1	24.10.2006 17:56:21	.sza	




As with other result list columns, you can switch to a view with text that displays information about the icon symbols in the header and result list columns:























## Checking outdated documents during printing, conversion and export, as well as when changing workflow status

In connection with the up-to-dateness of documents, the **HELiOS Options** for printing documents via the Spooler and conversions, for exporting documents from HELiOS and for changing workflow status offer you advanced options for setting how to proceed with documents that are not current or with a document currency status that is not up to date:




**HELiOS Options**

-  General
-  Find
-  Input
-  Display
-  Result lists
-  Project and Folder structures
-  Product structures
-  Print / Convert
-  **Import / Export**
-  Workflow
-  Log
-  E-mail
-  Preview
-  Plugins
-  Database
-  HELiOS Desktop



**Settings for import and export**

**Import**  
 Allow import on document masters whose file was originally saved within another application:  
☒ No  
☐ Yes and keep model/document structure  
☐ Yes and delete model/document structure


**Export**  
☐ Only allow current documents for export  
☒ Interpret documents with undeterminable status as current  
☐ Interpret documents with undeterminable status as not current

















Generated file name for the export  


Files:	Standard
Files of project:	Standard
Files of folder:	Standard
Files via drag & drop:	Standard
Pack & Go:	Standard

 Manage...

Apply
Cancel
OK


**HELiOS Options**

-  General
-  Find
-  Input
-  Display
-  Result lists
-  Project and Folder structures
-  Product structures
-  Print / Convert
-  Import / Export
-  **Workflow**
-  Log
-  E-mail
-  Preview
-  Plugins
-  Database
-  HELiOS Desktop


**Settings for workflows**


**General**  
 The following applies to all workflows and statuses:  
☒ Interpret documents with undeterminable status as current  
☐ Interpret documents with undeterminable status as not current  
 Select the workflow statuses for which the system should check whether the corresponding document is up to date when changing documents to this status. The workflow status change of documents that are not up to date is then prevented.  
 Workflow: general document (R)

Workflow status
<input type="checkbox"/> In Progress
<input checked="" type="checkbox"/> Checkup
<input checked="" type="checkbox"/> Released

**Role workflow**  
 Switch status of "traffic light" to "Yellow" in time management  

0

 Days before target date

 Manage...


Apply
Cancel
OK

## Deleting referenced articles/documents in the model structure

If you attempt to delete CAD-relevant articles from referenced structures, you will receive a warning message:



The corresponding articles are initially deselected for deletion in the selection dialogue window that opens.




## Use in articles, Use in documents

With the update to HELiOS 2026, you will find two different tabs for article use in the article detail dialogue:

- **Use in articles**


This refers to usage based on the product structure.

In earlier HELiOS versions, the tab was simply named "Use".



- **Use in documents**

This new tab lists all documents in whose model structure the active article is stored.



## Sorting the "Utilized items" result list

The option introduced with HELiOS 2025 Service Pack 2 to define sorting criteria for result lists on the **Sort** tab is also available in the special product structure- and article context-related **Utilized items** result list.

The screenshot displays the HELiOS software interface. The main window shows the 'Utilized items' result list under the 'Utilized articles' tab. The list contains four items with columns for Item, Qty., CAD li, Article number, Ir, Designation, Designation, Standard designation, Creation date, and Created by.

Item	Qty.	CAD li	Article number	Ir	Designation	Designation	Standard designation	Creation date	Created by
1	1	<input checked="" type="checkbox"/>	SN-000005	<input checked="" type="checkbox"/>	Pinion assembly			02.10.2006	Konstrukteur1
20	1	<input checked="" type="checkbox"/>	SN-000004	<input checked="" type="checkbox"/>	Gear wheel assembly			02.10.2006	Konstrukteur1
3	1	<input checked="" type="checkbox"/>	SN-000003	<input checked="" type="checkbox"/>	Housing assembly			02.10.2006	Konstrukteur1
4	1	<input checked="" type="checkbox"/>	SN-000002	<input checked="" type="checkbox"/>	Clamping element			02.10.2006	Konstrukteur1

The 'Edit attribute configuration' dialog box is open, showing the 'Available attributes' list on the left and the 'Selected attributes' list on the right. The 'Sort' tab is selected in the 'Selected attributes' list.

**Available attributes:**

Type	Designation	Attribute name
<input checked="" type="checkbox"/>	Item number	POSITIONSNUMMER
<input checked="" type="checkbox"/>	Qty.	UI_PositionCount
<input checked="" type="checkbox"/>	CAD link	HEL_CAD_RELEVANCE
<input type="checkbox"/>	Angle 1 of section schema [°]	PROFIL_SCHNITTW1
<input type="checkbox"/>	Angle 2 of section schema [°]	PROFIL_SCHNITTW2
<input type="checkbox"/>	Angle bottom/left - XZ [°]	PROFIL_SCHNITTW2XZ
<input type="checkbox"/>	Angle bottom/left - YZ [°]	PROFIL_SCHNITTW2YZ
<input type="checkbox"/>	Angle top/right - XZ [°]	PROFIL_SCHNITTW1XZ
<input type="checkbox"/>	Angle top/right - YZ [°]	PROFIL_SCHNITTW1YZ
<input type="checkbox"/>	Base quantity	MENGE1
<input type="checkbox"/>	Beam, Web A	PROFIL_ASTEG
<input type="checkbox"/>	Comment	BEMERKUNG
<input type="checkbox"/>	Commercial weight [kg]	HANDELSGEWICHT
<input type="checkbox"/>	Commercial weight per length [kg]	HANDELSGEWICHT_M
<input type="checkbox"/>	Designation 1	BENENNUNG


**Selected attributes:**

Type	Object type	Designation	Sort sequence	Format
<input checked="" type="checkbox"/>	Item number		Ascending	Text
<input checked="" type="checkbox"/>	Comment		Ascending	Text

The 'Sort' tab is selected in the 'Selected attributes' list. The 'Attribute description' field is empty. The 'Show column for attribute names' checkbox is checked.

## Convert: Further settings

In the **Convert file** dialogue window for documents you can now find the new **Further settings...** button.




By clicking on this button, you can override the conversion options specified by the HELiOS Spooler for the active conversion process, if necessary.

The conversion to the following formats generally offers advanced settings:


- PDF (from SZA, IDW or DWG files)
- STEP (from IPT or IAM format)
- Image formats(BMP, GIF, JPG, PNG and TIFF) from Inventor files (IDW, DWG, IPT and IAM)
- STL (from IPT or IAM files)

A target format-specific dialogue window opens with the Spooler options.


For PDF files, for example, the following options are available:




Clicking on **Page margins** opens a sub-dialogue box for changing the page margin dimensions



The following options are available for the STEP format:




The following options are available for image formats::



When converting to STL format, you have the following additional settings options:



 **Further settings**

**General**

Format: ☒ Binary ☐ ASCII

Unit: 

Centimeter

Structure: 

One file

Import colours: ☒

**Resolution**

☐ High

☒ Medium

☐ Low

☐ BREP

☐ User-defined

Surface area deviation: 

60 %

Normal deviation: 

14

Maximum edge length: 

100 %


Aspect ratio: 

40



Cancel


OK

HELiOS remembers the changed settings and offers them again the next time you convert. Clicking the **Reset**  button at the bottom left of the dialogue window restores the default settings specified by the server.

## Export dialogue: Progress bar with context determination

In the export dialogue for HELiOS documents, the respective context (article, project, folder) is always determined in order to build up the result list.

You will see a progress bar while this process is running.




## Job overview

Similar to the revised interface of the **HELiOS Spooler Admin Tool**, the **Job overview** of print/conversion jobs, which you can access in the HELiOS Desktop, has also been expanded:

There you will find corresponding buttons for controlling the jobs.


It is also possible to execute these for multiple job selections.




## HELiOS Options: Plugins


### Update and save selected plugins

At **HELiOS Options > Plugins**, two new edit buttons have been added for managing plugins:




By selecting a plugin in the list and clicking on  **Update selected plugin** you can perform an update without replacing the plugin in the file system or by deleting and adding it again.

Here, too, you can decide in the Windows file selection dialogue at the bottom right whether you want to select only the plugin DLL or the entire ZIP archive of the plugin for updating.



This option now also appears when transferring plugins to HELiOS.

By selecting a plugin and clicking  **Save selected plugin**, you can save a plugin to your local system (or to a network drive, for example). Multiple selection is not possible here.


Saving then exports the selected plugin and all dependent files as a ZIP archive.

This provides you with a simple way to exchange plugins between different workstations.

## Plugin directory

At the bottom of the Plugins options window, you will see the system path of your plugins integrated in HELiOS in the row next to **Plugin directory**.

Clicking on **Open** to the right of it will open it directly in Windows Explorer.



## Performance improvements for viewing

In HELiOS 2025, preview displays and viewer integrations were revised and improved. With the update to HELiOS 2026, further performance optimisations were made in this area.

When previewing IFC files in HELiOS, a reduction in main memory requirements and thus an increase in viewer performance could be achieved.


A progress bar is only displayed for asynchronously started viewers – including the preview mechanisms for MS Office files, ZIP archive viewers, and all viewers based on WebView2 – if a corresponding delay justifies it. For very short loading times, the unnecessary, very brief appearance of a progress bar is avoided.

# HELIOS in HiCAD

## Major Release

### Model structure


The **Model structure** tab of a HELIOS document master mask displays the document structure of HiCAD files (.SZA, .KRA). With the update to HELIOS 2026, this has been expanded to transfer and display the part structure from HiCAD:




In addition to the icons for the respective part type, the model structure tree also displays the icons for referencing and dependent parts.

In addition, as part of the expansion of the model structure, some interface elements have also been expanded so that they now correspond to what you are used to in HiCAD.

The context menu in the **Model** column of the **Model structure** results list depends on the existing context, i.e. the respective article, document or other object (or, if applicable, no) context menu is displayed.



In addition, you can transfer the **Model structure** of HiCAD drawings directly from the results list to the **Report Manager**, as you are already accustomed to doing in other areas of HELIOS.








## BOM-relevance of auxiliary and environment parts

Since auxiliary and environment parts are often integrated into a drawing but should not usually appear in bill of materials, HiCAD 2026 supports the following procedure with regard to referencing, BOM-relevance and the transfer of the model structure to HELiOS: to create auxiliary and environment parts outside the main assembly so that subsequent changes to already itemised parts do not lead to inconsistencies in item numbers and texts.

The following changes have been made for this purpose:



In the dialogue window of the HiCAD function **Itemise**, with options **1...n**, the option **Only within main assembly** has been added to the **General** tab, in the **Numbering** area.

The checkbox **Only consider parts within the main assembly** was added to the General area of the **Bill of Materials (BOM)**  dialogue.

Two default settings were adjusted in the **Configuration Editor**:

- The referencing setting of the attribute **BOM-relevant** at **System settings > Attribute management > Attributes** has been changed from "Do not transfer" to **Standard behaviour**.
- At **Modelling > Change of part structure > Moving of parts out of main assembly allowed**, the checkbox is now active by default for all industries. Previously, this was only the case for the Steel Engineering module.

## Virtual attributes: Document number via linked article

To output HELiOS document numbers via their link to an article, new virtual attributes have been introduced in HELiOS that take into account the different link classes:


Virtual attribute	Designation	Description
VA_LINKED_SZA	Linked drawing	This attribute displays the document number of a document linked to an article via the link class <b>Bauteil-Konstruktion</b> .
VA_LINKED_SPL	Linked pipe spool drawing	This attribute displays the document number of a document linked to an article via the link class <b>Pipeline-Spool</b> .
VA_LINKED_ISO	Linked iso-metry	This attribute shows the document number of a document linked to an article via the link class <b>Pipeline-Isometry</b> .
VA_LINKED_LAY	Linked layout plan	This attribute shows the document number of a document linked to an article via the link class <b>Pipeline-Layoutplan</b> .



### Please note:

If there is more than one linked document, the document number of the first document found is returned.

You can find the new attributes in the HiCAD dialogue for annotation tags:



## Hiding internal HELiOS attributes

Internal attributes are system attributes of HELiOS that are generally not relevant for end users when sorting result lists. They are therefore hidden by default in the attribute configuration, but can be displayed by deselecting the checkbox.


In HiCAD attribute selection masks, such as the Annotation Editor, the internal HELiOS attributes are now hidden alongside the internal HiCAD attributes.

# HELiOS Spooler

## Major Release


### HELiOS Spooler Admin Tool

Mit dem Update auf HELiOS 2026 finden Sie das **HELiOS Spooler Admin Tool** in einer überarbeiteten Form vor.




In der neuen Benutzeroberfläche steht Ihnen ein, an verschiedene Positionen andockbares **Eigenschaften**-Fenster zur Verfügung, wie Sie es etwa aus den Explorer-Bereichen des HELiOS Desktop kennen.

Auch im **HELiOS Spooler Admin Tool** können Sie den vollen Umfang einer Ergebnislistenkonfiguration nutzen, bei der Sie Attribute speziell für Druckaufträge in der Kategorie **Job** finden.



Über die neue Ribbon-Leiste des Admin Tools haben Sie außerdem die Möglichkeit, Supportanfragen oder Fernwartungssitzungen zu starten, sowie Dateien in das ISD Filecenter hochzuladen:



## Improvements to the priority processing of print and conversion jobs

For conversion jobs sent by clients running older versions of HELiOS to a current version of the HELiOS Spooler, inconsistencies could occur in the processing of a job's priority, which can generally be set by the user.

These have been fixed with the update to HELiOS 2026.

## HELiOS MS Office Interface

### Major Release

#### Support of Office 2024

The current versions of HELiOS and the HELiOS Spooler support MS Office 2024.



**Legal notes**

© 2025 ISD ® Software und Systeme GmbH. All rights reserved.

This User Guide and the software described herein are provided in conjunction with a license and may only be used or copied in accordance with the terms of the license. The contents of this User Guide solely serve the purpose of information; it may be modified without prior notice and may not be regarded as binding for the ISD Software und Systeme GmbH. The ISD Software und Systeme GmbH does not assume any responsibility for the correctness or accuracy of the information provided in this document. No part of this document may be reproduced, saved to databases or transferred in any other form without prior written permission by the ISD Software und Systeme GmbH, unless expressly allowed by virtue of the license agreement.

All mentioned products are trademarks or registered trademarks of their respective manufacturers and producers.





### Your local contact

We attach great importance to the direct contact with our customers and partners, because only a lively dialogue and constant exchange with practice ensure application-oriented software development.

Feel free to contact us! Whether at our headquarter in Dortmund or at one of our branches and subsidiaries in your vicinity - we will be happy to answer all your questions about our products and services. We are looking forward to hearing from you!

### Headquarter Dortmund

ISD Software und Systeme GmbH

Hauert 4

D-44227 Dortmund

Phone +49 231 9793-0

[info@isdgroup.com](mailto:info@isdgroup.com)

ISD locations worldwide at [www.isdgroup.com](http://www.isdgroup.com)